


Service

Marine Generator Sets



Models:

5EOZ

8EOZ

9EOZ

10EOZ

4EFOZ

6.5EFOZ

8EFOZ

9EFOZ

ISO 9001
KOHLER
POWER SYSTEMS
NATIONALLY REGISTERED

KOHLER[®]
POWER SYSTEMS

TP-6053 7/04a

Table of Contents

Safety Precautions and Instructions	I		
Introduction	i		
Service Assistance	i		
Section 1 Specifications	1		
1.1 General	1		
1.2 Service Views	2		
1.3 Engine	5		
1.4 Generator	6		
Section 2 Scheduled Maintenance	7		
2.1 General	7		
2.2 Lubrication System	7		
2.3 Battery	8		
2.4 Generator Storage	9		
Section 3 Intake and Exhaust System	11		
3.1 Air Intake Silencer/Filter	11		
3.2 Exhaust System	11		
3.3 Mixing Elbow	11		
Section 4 Fuel System	13		
4.1 General	13		
4.2 Fuel Specifications	13		
4.3 Fuel Filter	13		
4.4 Bleed the Fuel System	14		
4.5 Fuel Solenoid	15		
4.6 Fuel Pump	16		
4.7 Governor	17		
Section 5 Cooling System	19		
5.1 General	19		
5.2 Water-Cooled Exhaust Manifold	20		
5.3 Closed Heat Exchanger	20		
5.4 Fill Check and Coolant	20		
5.5 Flush and Clean Cooling System	20		
5.6 Pressure Cap	21		
5.7 Impeller Inspection and Replacement	21		
5.8 Belt Tension	22		
5.9 Siphon Break	23		
5.10 Anticorrosion Zinc Anode	24		
Section 6 Controller Troubleshooting	25		
6.1 General	25		
6.2 Controller Sequence of Operation	25		
6.2.1 Start	25		
6.2.2 Run	25		
6.2.3 Stop	26		
6.3 Engine Safety Shutdown Switches	26		
6.3.1 Low Oil Pressure (LOP) Shutdown	26		
6.3.2 High Water Temperature and High Exhaust Temperature Shutdown Switch	26		
6.4 Controller Circuit Board	27		
6.5 Troubleshooting	28		
Section 7 Generator Troubleshooting	33		
7.1 General	33		
7.2 General Troubleshooting	33		
7.3 Separate Excitation	34		
7.4 PowerBoost III Voltage Regulators	34		
7.4.1 Voltage Regulator Test	35		
7.4.2 Voltage Regulator Adjustment	35		
7.5 Exciter Field	36		
7.6 Exciter Armature	37		
7.7 Rectifier Module	38		
7.8 Rotor	38		
7.9 Stator	39		
Section 8 Component Troubleshooting	41		
8.1 General	41		
8.2 Remote Panels (Optional)	43		
Section 9 Generator Disassembly/ Reassembly	45		
9.1 Disassembly	45		
9.2 Reassembly	47		
Section 10 Voltage Reconnection and Wiring Diagrams	51		
10.1 Voltage Reconnection	51		
10.1.1 100-120-Volt Configurations	51		
10.1.2 100-120/200-240-Volt Configurations	52		
10.1.3 200-240-Volt Configurations	52		
10.2 Marine Manual (Ship-to-Shore) Transfer Switch	53		
10.3 Wiring Diagram, Schematic	54		
10.4 Wiring Diagram, Point-to-Point	55		
10.5 Remote Start Panel	56		
10.6 Remote Start and 2-Meter Panel	56		
10.7 Remote Start and 4-Meter Panel	57		
Appendix A Abbreviations	A-1		
Appendix B Common Hardware Application Guidelines	A-3		
Appendix C General Torque Specifications	A-4		
Appendix D Common Hardware Identification	A-5		
Appendix E Common Hardware List	A-6		

Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**


NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Place the generator set start/stop switch in the STOP position. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

Battery

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.


Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire


⚠ WARNING

<p>Fire. Can cause severe injury or death.</p> <p>Do not smoke or permit flames or sparks near fuels or the fuel system.</p>

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner/silencer removed.

Combustible materials. A sudden flash fire can cause severe injury or death. Do not smoke or permit flames or sparks near the fuel system. Keep the compartment and the generator set clean and free of debris to minimize the risk of fire. Wipe up spilled fuels and engine oil.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

Exhaust System

⚠ WARNING

<p>Carbon monoxide. Can cause severe nausea, fainting, or death.</p> <p>The exhaust system must be leakproof and routinely inspected.</p>

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
 - Physical fatigue, weakness in joints and muscles
 - Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
 - Stomachache, vomiting, nausea
- If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.


Copper tubing exhaust systems. Carbon monoxide can cause severe nausea, fainting, or death. Do not use copper tubing in diesel exhaust systems. Sulfur in diesel exhaust causes rapid deterioration of copper tubing exhaust systems, resulting in exhaust/water leakage.

Inspecting the exhaust system. Carbon monoxide can cause severe nausea, fainting, or death. For the safety of the craft's occupants, install a carbon monoxide detector. Consult the boat builder or dealer for approved detector location and installation. Inspect the detector before each generator set use. In addition to routine exhaust system inspection, test the carbon monoxide detector per the manufacturer's instructions and keep the detector operational at all times.

Operating the generator set. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Use the following precautions when installing and operating the generator set. Do not install the exhaust outlet where exhaust can be drawn in through portholes, vents, or air conditioners. If the generator set exhaust discharge outlet is near the waterline, water could enter the exhaust discharge outlet and close or restrict the flow of exhaust. Never operate the generator set without a functioning carbon monoxide detector. Be especially careful if operating the generator set when moored or anchored under calm conditions because gases may accumulate. If operating the generator set dockside, moor the craft so that the exhaust discharges on the lee side (the side sheltered from the wind). Always be aware of others, making sure your exhaust is directed away from other boats and buildings. Avoid overloading the craft.

Fuel System

WARNING



Explosive fuel vapors. Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

Draining the fuel system. Explosive fuel vapors can cause severe injury or death. Spilled fuel can cause an explosion. Use a container to catch fuel when draining the fuel system. Wipe up spilled fuel after draining the system.

Installing the fuel system. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Do not modify the tank or the propulsion engine fuel system. Equip the craft with a tank that allows one of the two pickup arrangements described in the installation section. The tank and installation must conform to USCG Regulations.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Pipe sealant. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Use pipe sealant on all threaded fittings to prevent fuel leakage. Use pipe sealant that resists gasoline, grease, lubrication oil, common bilge solvents, salt deposits, and water.

Ignition-protected equipment. Explosive fuel vapors can cause severe injury or death. Gasoline vapors can cause an explosion. USCG Regulation 33CFR183 requires that all electrical devices (ship-to-shore transfer switch, remote start panel, etc.) must be ignition protected when used in a gasoline and gaseous-fueled environment. The electrical devices listed above are not ignition protected and are not certified to operate in a gasoline and gaseous-fueled environment such as an engine room or near fuel tanks. Acceptable locations are the wheelhouse and other living areas sheltered from rain and water splash.

Hazardous Noise

CAUTION




Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage


WARNING



Hazardous voltage. Moving rotor. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

CAUTION



Welding the generator set. Can cause severe electrical equipment damage.

Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Disconnecting the electrical load. Hazardous voltage can cause severe injury or death. Disconnect the generator set from the load by opening the line circuit breaker or by disconnecting the generator set output leads from the transfer switch and heavily taping the ends of the leads. High voltage transferred to the load during testing may cause personal injury and equipment damage. Do not use the safeguard circuit breaker in place of the line circuit breaker. The safeguard circuit breaker does not disconnect the generator set from the load.

Welding the generator set. Can cause severe electrical equipment damage. Before welding the generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine battery-charging alternator connections. (5) Attach the weld ground connection close to the weld location.


Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.


Testing the voltage regulator. Hazardous voltage can cause severe injury or death. High voltage is present at the voltage regulator heat sink. To prevent electrical shock do not touch the voltage regulator heat sink when testing the voltage regulator. (PowerBoost™, PowerBoost™ III, and PowerBoost™ V voltage regulator models only)

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Connect the generator set to the building/marina electrical system only through an approved device and after the building/marina main switch is opened. Backfeed connections can cause severe injury or death to utility personnel working on power lines and/or personnel near the work area. Some states and localities prohibit unauthorized connection to the utility electrical system. Install a ship-to-shore transfer switch to prevent interconnection of the generator set power and shore power.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically. (600 volts and under)

Hot Parts



⚠ WARNING

Hot coolant and steam. Can cause severe injury or death.
Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure.



⚠ WARNING

Hot engine and exhaust system. Can cause severe injury or death.
Do not work on the generator set until it cools.


Checking the coolant level. Hot coolant can cause severe injury or death. Allow the engine to cool. Release pressure from the cooling system before removing the pressure cap. To release pressure, cover the pressure cap with a thick cloth and then slowly turn the cap counterclockwise to the first stop. Remove the cap after pressure has been completely released and the engine has cooled. Check the coolant level at the tank if the generator set has a coolant recovery tank.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Moving Parts

⚠ WARNING	
	
Hazardous voltage. Moving rotor. Can cause severe injury or death.	
Operate the generator set only when all guards and electrical enclosures are in place.	

⚠ WARNING	
	
Rotating parts. Can cause severe injury or death.	
Operate the generator set only when all guards, screens, and covers are in place.	


⚠ WARNING

Airborne particles. Can cause severe injury or blindness.
Wear protective goggles and clothing when using power tools, hand tools, or compressed air.

Tightening the hardware. Flying projectiles can cause severe injury or death. Loose hardware can cause the hardware or pulley to release from the generator set engine and can cause personal injury. Retorque all crankshaft and rotor hardware after servicing. Do not loosen the crankshaft hardware or rotor throbolt when making adjustments or servicing the generator set. Rotate the crankshaft manually in a clockwise direction only. Turning the crankshaft bolt or rotor throbolt counterclockwise can loosen the hardware.

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Sound shield removal. Exposed moving parts can cause severe injury or death. The generator set must be operating in order to perform some scheduled maintenance procedures. Be especially careful if the sound shield has been removed, leaving the belts and pulleys exposed. *(Sound-shield-equipped models only)*

Notice

NOTICE
This generator set has been rewired from its nameplate voltage to

246242

NOTICE

Voltage reconnection. Affix a notice to the generator set after reconnecting the set to a voltage different from the voltage on the nameplate. Order voltage reconnection decal 246242 from an authorized service distributor/dealer.

NOTICE

Hardware damage. The engine and generator set may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

NOTICE

When replacing hardware, do not substitute with inferior grade hardware. Screws and nuts are available in different hardness ratings. To indicate hardness, American Standard hardware uses a series of markings, and metric hardware uses a numeric system. Check the markings on the bolt heads and nuts for identification.

NOTICE

Fuse replacement. Replace fuses with fuses of the same ampere rating and type (for example: 3AB or 314, ceramic). Do not substitute clear glass-type fuses for ceramic fuses. Refer to the wiring diagram when the ampere rating is unknown or questionable.

NOTICE

Saltwater damage. Saltwater quickly deteriorates metals. Wipe up saltwater on and around the generator set and remove salt deposits from metal surfaces.

This manual provides troubleshooting and repair instructions for 5-10EOZ/EFOZ model generator sets, controllers, and accessories.

Refer to the engine service manual for generator set engine service information.

x:in:001:001

This manual may be used for models not listed on the front cover.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The equipment service requirements are important for safe and efficient operation. Inspect the parts often and perform required service at the prescribed intervals. Maintenance work must be performed by appropriately skilled and suitably-trained maintenance personnel familiar with generator set operation and service.

x:in:001:003

Service Assistance

For professional advice on generator power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric
- Visit the Kohler Power Systems website at KohlerPowerSystems.com
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product
- Call toll free in the US and Canada 1-800-544-2444
- Outside the US and Canada, call the nearest regional office

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems
ZI Senia 122
12, rue des Hauts Flouviars
94517 Thiais Cedex
France
Phone: (33) 1 41 735500
Fax: (33) 1 41 735501

Asia Pacific

Power Systems Asia Pacific Regional Office
Singapore, Republic of Singapore
Phone: (65) 6264-6422
Fax: (65) 6264-6455

China

North China Regional Office, Beijing
Phone: (86) 10 6518 7950
(86) 10 6518 7951
(86) 10 6518 7952
Fax: (86) 10 6518 7955

East China Regional Office, Shanghai
Phone: (86) 21 6288 0500
Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office
Bangalore, India
Phone: (91) 80 3366208
(91) 80 3366231
Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office
Tokyo, Japan
Phone: (813) 3440-4515
Fax: (813) 3440-2727

Latin America

Latin America Regional Office
Lakeland, Florida, USA
Phone: (863) 619-7568
Fax: (863) 701-7131

1.1 General

This manual covers the operation, maintenance, troubleshooting, and repair of the alternating current marine generator sets.

Have an authorized service dealer/distributor perform required servicing to assure your unit continues to meet USCG requirements.

Please take a few moments to read this manual, then carefully follow all service recommendations. See Figure 1-1 through Figure 1-3 for identification and location of components.

The 5EOZ/4EFOZ models are powered by a Yanmar three-cylinder, water-cooled, four-cycle diesel engine. The three-cylinder engine with heat exchanger is model 3TNE68.


The 8EOZ/6.5EFOZ models are powered by a Yanmar three-cylinder, water-cooled, four-cycle diesel engine. The three-cylinder engine with heat exchanger is model 3TNE74.

The 9EOZ/8EFOZ models are powered by a Yanmar three-cylinder, water-cooled, four-cycle diesel engine. The three-cylinder engine with heat exchanger is model 3TNE78A.

The 10EOZ/9EFOZ models are powered by a Yanmar three-cylinder, water-cooled, four-cycle diesel engine. The three-cylinder engine with heat exchanger is model 3TNE82A.


Kohler Co. develops all Kohler® marine generator set ratings using accepted reference conditions of 25°C (77°F) and pressure of 98.9 kPa (29.2 in. Hg) dry barometer. ISO 3046 and ISO 8528-1 include reference conditions and output calculations. Obtain technical information bulletin (TIB-101) on ratings guidelines for complete ratings definitions.

1.2 Service Views



DK-250000


Figure 1-1 Generator Set Service View (5EOZ/4EFOZ)



A-358000A-A

- | | |
|--|---|
| 1. Start/stop switch | 18. Fuel filter |
| 2. Controller | 19. Oil filter |
| 3. Nameplate | 20. Oil drain valve and hose |
| 4. Hourmeter | 21. Fuel feed pump |
| 5. DC circuit breaker | 22. Oil check |
| 6. AC circuit breaker | 23. Fuel inlet connection |
| 7. Air cleaner | 24. Low oil pressure safety shutdown switch |
| 8. Coolant recovery bottle | 25. Wet exhaust manifold |
| 9. Pressure cap | 26. Thermostat |
| 10. Fuel return connection | 27. AC load lead connector |
| 11. High water temperature shutdown switch | 28. Remote start connector |
| 12. Oil fill | 29. High exhaust temperature safety shutdown switch |
| 13. Seawater pump (water inlet) | 30. Mixing elbow |
| 14. V-belts | 31. Engine starter |
| 15. Heat exchanger | 32. Water temperature sender |
| 16. Coolant drain (fresh water) | 33. Battery charging alternator |
| 17. Anticorrosion zinc anode | |

Figure 1-2 Generator Set Service View (8EOZ/6.5EFOZ)



A-358000A-A

- | | |
|---|---|
| 1. Start/stop switch | 18. Fuel feed pump |
| 2. Controller | 19. Fuel inlet connection |
| 3. Nameplate | 20. Oil check |
| 4. Hourmeter | 21. Coolant drain (fresh water) |
| 5. DC circuit breaker | 22. Fuel return |
| 6. AC circuit breaker | 23. Wet exhaust manifold |
| 7. Air cleaner | 24. Thermostat |
| 8. Coolant overflow bottle | 25. AC load lead connector |
| 9. Low oil pressure safety shutdown switch | 26. Remote start connector |
| 10. Pressure cap | 27. High exhaust temperature safety shutdown switch |
| 11. Oil fill | 28. Mixing elbow |
| 12. High water temperature safety shutdown switch | 29. Anticorrosion zinc anode |
| 13. V-belts | 30. Engine starter |
| 14. Seawater pump (water inlet) | 31. Heat exchanger |
| 15. Fuel filter | 32. Coolant drain (fresh water) |
| 16. Oil drain valve and hose | 33. Water temperature sender |
| 17. Oil filter | 34. Battery charging alternator |

Figure 1-3 Generator Set Service View (9/10EOZ and 8/9EFOZ)

1.3 Engine

Generator Model	5EOZ/4EFOZ	8EOZ/6.5EFOZ	9EOZ/8EFOZ	10EOZ/9EFOZ
Engine manufacturer	Yanmar			
Engine model	3TNE68	3TNE74	3TNE78A	3TNE82A
Number of cylinders	3			
Cylinder block material	Cast iron			
Cylinder head material	Cast iron			
Piston rings	2 compression/1 oil			
Crankshaft material	Stamped forging			
Connecting rod material	Forged carbon steel			
Governor	Centrifugal, mechanical			
Bore x stroke, mm (in.)	68 x 72 (2.67 x 2.83)	74 x 78 (2.91 x 3.07)	78 x 84 (3.07 x 3.30)	82 x 84 (3.22 x 3.30)
Displacement, L (CID)	0.784 (47.83)	1.006 (61.39)	1.204 (73.45)	1.330 (81.14)
Compression ratio	23.0:1		18.0:1	
Horsepower, 60/50 Hz	10.1/8.4	14/11.6		17.7/14.8
RPM, 60/50 Hz	1800/1500			
Direction of rotation (as viewed from generator end)	Counterclockwise			
Lubrication system	Pressure, trochoid pump			
Lube oil capacity w/filter, L (qts.)	3 (3.2)	2.4 (2.3)	5.2 (5.5)	3.4 (3.6)
Oil recommendation, API	CD, CD/CC, or CC			
Engine firing order (#1 cylinder nearest to flywheel)	1-3-2			
Fuel injection timing (BTDC)	14° ± 1°		16° ± 1°	10° ± 1°
Fuel injection pressure, kg/cm sq. (psi)	120 (1706)			200 (2844)
Combustion system	Indirect injection, swirl precombustion chamber		Direct injection	
Battery voltage	12 volt, negative ground			
Battery recommendation, min.	500 CCA, 100 amp hr.			
Battery charging (alternator)	40 amps @ 12 volts		50 amps @ 12 volts	
Fuel recommendation	Diesel, ISO 8217 DMA, BS 2869 Part 1 Class A1 or Part 2 Class A2			
Fuel shutoff solenoid system	Electric			
Fuel feed pump	Electric, rotary vane			
Fuel pump priming	Electric			
Max. recommended fuel pump lift, m (ft.)	1.2 (4)			
Coolant capacity, L (qts.)	1.8 (1.9)	3.9 (4.12)		5.2 (5.5)
Coolant recovery tank capacity, L (oz.)	0.24 (8.0)			
Recommended coolant	50% ethylene glycol; 50% clean, softened water			
Thermostat	71°C (160°F)			
Pressure cap rating, kPa (psi)	96.5 (14.0)			
Starter motor	0.8 kW Bendix automotive type		1.8 kW Bendix, gear-reduction automotive type	

Engine (continued)

Generator Model	5EOZ/4EFOZ	8EOZ/6.5EFOZ	9EOZ/8EFOZ	10EOZ/9EFOZ
Intake/exhaust valve clearance (cold), mm (in.)	0.15-0.25 (0.006-0.010)			
Belt tension (force) @ 10 kg (22 lbs.), mm (in.)	10-15 (0.4-0.6)			
Flex plate to rotor bolt torque (3/8-16), Nm (ft. lbs.)	45 (35)	36.6 (27)	45 (35)	38 (28)
Flex plate to flywheel bolt torque (M8-1.25), Nm (ft. lbs.)	25 (20)	38 (28)	25 (20)	19 (14)
Overbolt torque (M10-1.5), Nm (ft. lbs.)	45 (35)	34 (25)	45 (35)	34 (25)
Inlet water line hose ID (seawater pump inlet), mm (in.)	16 (5/8)			
Outlet water line hose ID (mixing elbow outlet), mm (in.)	51 (2)			
Fuel inlet (fuel pump inlet)	1/4 NPT			
Fuel return size type	1/4 NPT			

1.4 Generator

Generator Model	5/8EOZ and 4/6.5EFOZ	9/10EOZ and 8/9EFOZ
Hot exciter field voltage/current readings at rated voltage*		
No load (63 Hz) (volts/amps)	19/0.9	12/0.8
Full load (60 Hz) (volts/amps)	32/1.5	33/2.2
Resistor (F1 lead to exciter field) (ohms)	15 ±2	10 ±2
Cold exciter field resistance (ohms)	4.8	
Cold exciter armature resistance (ohms)	1.2	
Cold main field (rotor) resistance (ohms)	5.0	5.7
Stator output voltages with separately excited generator, using 12-volt battery (60 Hz only)*		
1-2, 3-4, 33-44 (volts)	81	115
33-55 (volts)	105	155
B1-B2 (volts)	10	15
Cold stator resistance		
1-2, 3-4, 33-44 (ohms)	0.3	0.2
33-55 (ohms)	2.1	1.9
B1-B2 (ohms)	0.1	
* Includes resistor in exciter field circuit.		

Section 2 Scheduled Maintenance

2.1 General

⚠ WARNING




Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Place the generator set start/stop switch in the STOP position. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

⚠ WARNING



Rotating parts. Can cause severe injury or death.

Operate the generator set only when all guards, screens, and covers are in place.

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Sound shield removal. Exposed moving parts can cause severe injury or death. The generator set must be operating in order to perform some scheduled maintenance procedures. Be especially careful if the sound shield has been removed, leaving the belts and pulleys exposed.
(Sound-shield-equipped models only)

NOTICE

Saltwater damage. Saltwater quickly deteriorates metals. Wipe up saltwater on and around the generator set and remove salt deposits from metal surfaces.

Note: See the generator set operation manual for the service schedule and other service not included in this manual.

2.2 Lubrication System

The following paragraphs describe the engine lubrication system.

Use oil that meets the American Petroleum Institute (API) classification of CD, CC/CD, or CC. Using unsuitable oil or neglecting an oil change may result in damage and a shorter engine life. Figure 2-1 shows the recommended Society of Automotive Engineers (SAE) viscosity designation for given operating temperature ranges.

Note: Failure to observe these standards may cause inadequate lubrication/oil pressure and cold-starting difficulties.




Figure 2-1 Engine Oil Selection

Electric Oil-Drain/Oil-Fill Procedure

1. Connect the pump to the end of the oil-drain hose.
2. Place the pump outlet hose into a container. Remove the oil-fill cap(s). One is located near the top of the engine on the valve cover and one is located near the governor.
3. Activate the pump until all of the oil is removed. Allow ample time for all of the oil to drain.
4. Turn the valve at the base of the oil-drain hose to the closed position.
5. Replace the engine oil filter.
6. Fill the engine crankcase to the specified level with oil. The figures in Section 1 show typical oil fill locations. See Figure 2-1 for oil selection and Figure 2-2 for oil capacities.
7. Start the generator set and check for oil leaks.
8. Stop the generator set. Check the oil level. Add oil, as necessary, to bring the level up to the Max mark on the dipstick.

Model	L (Qts.)
5EOZ and 4EFOZ	3.0 (3.2)
8EOZ and 6.5EFOZ	2.3 (2.4)
9EOZ and 8EFOZ	5.2 (5.5)
10EOZ and 9EFOZ	5.2 (5.5)

Figure 2-2 Oil Capacities

2.3 Battery

Consult the battery manufacturer's instructions regarding battery care and maintenance.

WARNING



**Sulfuric acid in batteries.
Can cause severe injury or death.**

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

2.4 Generator Storage

Perform the generator storage procedure while the craft is afloat. Follow the procedure below when storing your generator set for 3 months or more.

Storage Procedure

1. Start and run the generator set until it reaches operating temperature, about 30 minutes.
2. Stop the generator set.
3. Change the oil and oil filter. See the generator set operation manual.
4. Drain the seawater from the heat exchanger by removing the coolant drain plug.
5. Close the seacock and remove the hose at the seacock. Place the hose in a container having approximately 3.7–7.5 L (1–2 gal.) of marine antifreeze. Use an environmentally safe marine antifreeze with corrosion inhibitors.
6. With a container at the exhaust outlet, run the generator set until coolant discharges at the exhaust outlet or until depleting the coolant mixture. Do not allow the coolant mixture to flow into waterways.
7. Stop the generator set.
8. Connect the hose to the seacock. Leave the seacock closed.
9. Check the coolant level in the heat exchanger and add coolant if necessary.
Note: Use antifreeze with the lowest available temperature rating.
10. Clean the exterior of the generator set and spread a light film of oil or silicon spray over any exposed surfaces which may be subject to rust or corrosion.
11. Disconnect and remove the battery. Place the battery in a dry location for the storage period. Recharge the battery once a month to maintain a full charge.
12. Cover the entire unit with a breathable dust cover.

Section 3 Intake and Exhaust System

3.1 Air Intake Silencer/Filter


A dry-type air cleaner silences and filters the intake air. The air intake silencer assembly connects to the intake manifold via a flexible hose.

At the interval specified in the service schedule, clean or replace the air intake silencer. Clean or replace the air cleaner more frequently in dirty, dusty conditions. Follow the procedure described below.

Air Cleaner Service/Replacement Procedure

1. Release the four spring clips to open the housing and remove the air silencer element.
2. Tap the element lightly against a flat surface to dislodge loose surface dirt. Do not clean the element in any liquid or use compressed air as these will damage the filter element.
3. Examine the element and its housing for damage and wear. Replace the element or its housing, if necessary.
4. Wipe the cover and base with a clean rag to remove any dirt. Make sure the sealing surfaces fit correctly and reattach the spring clips.

3.2 Exhaust System



Inspecting the exhaust system. Carbon monoxide can cause severe nausea, fainting, or death. For the safety of the craft's occupants, install a carbon monoxide detector. Consult the boat builder or dealer for approved detector location and installation. Inspect the detector before each generator set use. In addition to routine exhaust system inspection, test the carbon monoxide detector per the manufacturer's instructions and keep the detector operational at all times.

Check for exhaust leaks and blockages. Check the silencer and piping condition and check for tight exhaust system connections.

Inspect the exhaust system components (exhaust manifold, mixing elbow, exhaust line, hose clamps, silencer, and outlet flapper) for cracks, leaks, and corrosion.

- Check the hoses for softness, cracks, leaks, or dents. Replace the hoses as needed.
- Check for corroded or broken metal parts and replace them as needed.
- Check for loose, corroded, or missing clamps. Tighten or replace the hose clamps and/or hangers as needed.
- Check that the exhaust outlet is unobstructed.
- Visually inspect for exhaust leaks. Check for carbon or soot residue on exhaust components. Carbon and soot residue indicates an exhaust leak. Seal leaks as needed.
- Ensure that the carbon monoxide detector is (1) in the craft, (2) functional, and (3) energized whenever the generator set operates.

3.3 Mixing Elbow

Check the mixing elbow for carbon buildup and corrosion inside the pipe. Clean the residual carbon buildup with a wire brush. Inspect the exhaust manifold flange for cracking and corrosion. The mixing elbow combines high temperature exhaust and cooling seawater. The mixture, when exposed to engine vibration, makes conditions conducive to rapid deterioration and failure if not correctly maintained. If any damage is detected with the mixing elbow or other exhaust components, replace the damaged components to prevent engine exhaust (carbon monoxide) leakage.

4.1 General

In most installations, both the generator set and the propulsion engine operate from a common fuel tank with a dual dip tube arrangement. The generator set dip tube is shorter than the propulsion engine's dip tube. With this arrangement, fuel may not be available to the generator set when the fuel supply is low. See Figure 4-1 for a fuel system schematic.




Figure 4-1 Fuel System Schematic Typical

4.2 Fuel Specifications

Use a clean, good quality diesel fuel oil with a cetane number of 45 or greater. Clean fuel prevents diesel fuel injectors and pumps from clogging.

Fuel Recommendation	
United States	ISO 8217 DMA, BS 2869 Part 1 Class A1 or Part 2 Class A2
United Kingdom	BS 2869-1983, Part 2 Class A2
Germany	DIN 51 601-1978

4.3 Fuel Filter

The quality and condition of the fuel largely determine the filter's useful life. Replace the fuel filter element according to the service schedule. Section 1.2 shows the location of the fuel filter. There are two types of fuel filtering systems, the spin-on fuel filter and the fuel filter element. Use the applicable procedure below to replace the fuel filter. See Figure 4-2 or Figure 4-3.

Spin-On Fuel Filter Replacement Procedure

1. Place the generator set start/stop switch in the STOP position.
2. Disconnect the generator set engine starting battery, negative (-) lead first.
3. Close the fuel supply valve.
4. Remove the fuel filter. See Figure 4-2.
5. Clean the contact surface of the fuel filter adapter.
6. Lightly lubricate the gasket surface of the new fuel filter with fresh fuel. Thread the filter onto the adapter until the gasket makes contact; hand-tighten the filter an additional one-half turn.
7. Open the fuel supply valve.
8. Reconnect the generator set engine starting battery, negative (-) lead last.
9. Bleed the fuel system. See Section 4.4.




Figure 4-2 Spin-On Fuel Oil Filter

Fuel Filter Element Replacement Procedure

1. Place the generator set start/stop switch in the STOP position.
2. Disconnect the generator set engine starting battery, negative (-) lead first.
3. Close the fuel supply valve.
4. Remove the retaining ring, filter cup, o-ring, fuel filter element and spring.
5. Replace the fuel filter element and install as shown in Figure 4-3.
6. Open the fuel supply valve.
7. Reconnect the generator set engine starting battery, negative (-) lead last.
8. Bleed the fuel system. See Section 4.4.




Figure 4-3 Fuel Oil Filter Element

4.4 Bleed the Fuel System

Bleed the air from the fuel system to prevent starting failures and/or erratic operation. One or more of the following causes air to collect in the fuel system:

1. The generator set operates until the fuel supply is emptied.
2. The air leaks in the suction side of the fuel system.
3. Replacing the fuel filter.
4. Vapor lock.

Note: Connect the battery during the priming procedure to allow engine cranking. Do not allow the engine/generator to start. To prevent starting, *toggle* the start/stop switch by momentarily placing the start/stop switch in the START position for a few seconds and then placing the switch in the STOP position. Close the seacock during bleeding.

Fuel System Bleeding Procedure

1. Loosen the fuel filter screw at position 1. See Figure 4-4.
2. Toggle the start/stop switch until fuel, free of air bubbles, flows from the vent screw at position 1. Tighten the screw.
3. Loosen the fuel filter screw at position 2.
4. Toggle the start/stop switch until fuel, free of air bubbles, flows from the vent screw at position 2. Tighten the screw.
5. Loosen the fuel injection pump screw at position 5.
6. Toggle the start/stop switch until fuel, free of air bubbles, flows from the vent screw at position 5. Tighten the screw.




Figure 4-4 Fuel System Bleed Points, Typical

4.5 Fuel Solenoid

The fuel solenoid serves to pull the injector pump lever to the fuel-on position when energized. The fuel solenoid is spring loaded to return the injector-pump lever to the fuel-off position when deenergized.

The generators in this manual use a 3-lead fuel solenoid. This solenoid has a white lead (P) which energizes the pull-in coil only during cranking. During operation, the red lead energizes the hold coil and the black lead is the common ground.

Current (amps) and resistance readings are shown in Figure 4-5. Resistance readings determine if the solenoid windings are open or shorted. These readings must be taken with fuel solenoid disconnected from engine wiring harness.

Fuel Solenoid	Reading
Pull-In	50 Amps
Hold	1.0 Amps
Black-White (P) Leads	0.12-0.26 Ohms
Black-Red Leads	11-13 Ohms

Figure 4-5 Fuel Solenoid Readings

In addition to the ohmmeter test, check for smooth, non-binding movement of the plunger. It is important that the linkage between the fuel solenoid and the fuel injection pump lever be properly adjusted to allow the solenoid plunger to fully compress. Improper adjustment may cause burnout of the pull-in coil. If the fuel solenoid setting is suspected to be incorrect, use the following procedure to correct and see Figure 4-6.

Fuel Solenoid Adjustment Procedure

1. Remove the fuel solenoid linkage.
2. With the fuel solenoid's plunger fully compressed, align the linkage and check injection pump lever for travel. The fuel solenoid should fully compress and the injection pump lever should be 1.6 mm (0.05 in.) before the lever reaches the stop (internal full open) position.

Note: The fuel solenoid must compress (bottom) fully or burnout of the fuel solenoid pull-in coil will occur.

3. If the alignment is not correct, check the linkage and mounting brackets. Loosen locknuts and adjust the ball joint's length in or out to attain proper alignment. Tighten the locknut.




Figure 4-6 Fuel Solenoid Linkage

4.6 Fuel Pump

The fuel pump transfers fuel from a source to the fuel injection pump.

Fuel Pump Test Procedure

1. Remove the two leads from the terminals at the bottom of the fuel pump. The pump terminals are labeled (-) and (+). See Figure 4-7.
2. Connect the inlet side of the pump to a fuel source. Disconnect the outlet hose from the fuel filter and place the hose end in a container to catch the fuel.
3. Connect the positive (+) terminal of the 12-volt battery to the positive terminal of the fuel pump. Connect the negative terminal of the fuel pump to the negative (-) terminal of the battery. You should hear the pump operate and see the fuel discharge from the pump outlet. Replace the pump if it does not operate.




Figure 4-7 Fuel Pump

4.7 Governor

The centrifugal, mechanical governor keeps the engine speed constant by automatically adjusting the amount of fuel supplied to the engine according to changes in the load. No regular service is required on the governor. The factory adjusts the governor during run-in, and further adjustment should not be needed unless poor governor control develops after extended generator usage.

60 Hz generator sets are designed to operate at 57–63 Hz, 1800 rpm under full load and 1890 rpm under no load.

50 Hz generator sets are designed to operate at 47–53 Hz, 1500 rpm under full load and 1590 rpm under no load.

Check the engine speed using a frequency meter connected to the load leads. Loosen the locking nut on the speed adjusting screw. Turn the screw clockwise to increase the speed and frequency. Turn the screw counterclockwise to decrease the speed. Tighten the locknut at the new setting. See Figure 4-8 or Figure 4-9.




Figure 4-8 Governor, 5EOZ/4EFOZ




Figure 4-9 Governor, 8/9/10EOZ and 6.5/8/9EFOZ


Section 5 Cooling System

5.1 General

The heat exchanger cooling system consists of a heat exchanger with a coolant recovery tank, a thermostat, a rubber impeller seawater pump, a centrifugal-type engine circulating pump, a water-cooled exhaust manifold, and an exhaust mixer. See Figure 5-1 for cooling system components.

Checking the coolant level. Hot coolant can cause severe injury or death. Allow the engine to cool. Release pressure from the cooling system before removing the pressure cap. To release pressure, cover the pressure cap with a thick cloth and then slowly turn the cap counterclockwise to the first stop. Remove the cap after pressure has been completely released and the engine has cooled. Check the coolant level at the tank if the generator set has a coolant recovery tank.

⚠ WARNING



Hot coolant and steam. Can cause severe injury or death.

Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure.

NOTICE

Saltwater damage. Saltwater quickly deteriorates metals. Wipe up saltwater on and around the generator set and remove salt deposits from metal surfaces.




Figure 5-1 Cooling System Components

5.2 Water-Cooled Exhaust Manifold

Each generator set is equipped with a water-cooled exhaust manifold. Engine coolant circulates through the manifold, reducing the amount of heat radiated from the exhaust into the surrounding area. The engine thermostat is located in the manifold. See Section 1 for the thermostat location. See Figure 5-2 and Figure 5-3 for exhaust manifold bolt tightening sequence and torques.




Figure 5-2 Water-Cooled Exhaust Manifold Bolt Tightening Sequence

Model	Bolt Torque
5EOZ/4EFOZ	8 Nm (6 ft. lbs.)
8/9/10EOZ and 6.5/8/9EFOZ	19 Nm (14 ft. lbs.)

Figure 5-3 Exhaust Manifold Bolt Tightening Torques

5.3 Closed Heat Exchanger

In a closed cooling system, the seawater circulates through separate chambers within the heat exchanger to cool the engine water. The seawater then mixes with engine exhaust and ejects out the exhaust outlet. See Section 1.3 for the coolant capacities. Add an additional 0.24 L (8.0 oz.) of coolant to the coolant recovery tank.

5.4 Fill Check and Coolant

Keep the coolant recovery tank approximately 1/4 full. Before filling the cooling system, close all petcocks and tighten all hose clamps. Use a solution of 50% ethylene

glycol and 50% clean, softened water to inhibit rust and corrosion and to prevent freezing. Add additional coolant mixture, as necessary to the coolant recovery tank. Periodically check the coolant level on closed systems by removing the pressure cap. Do not rely solely on the level in the coolant recovery tank. Add fresh coolant mixture until the level is just below the overflow tube opening.

Do not add coolant to a hot engine. Adding coolant to a hot engine can cause the cylinder block or cylinder head to crack. Wait until the engine has cooled.

Note: Coolant solution. A coolant solution of 50% ethylene glycol provides freezing protection to -37°C (-34°F) and overheating protection to 129°C (265°F). A coolant solution with less than 50% ethylene glycol may not provide adequate freezing and overheating protection. A coolant solution with more than 50% ethylene glycol can cause engine or component damage. Do not use alcohol or methanol antifreeze or mix them with the specified coolant. Consult the engine manufacturer's operation manual for engine coolant specifications.

5.5 Flush and Clean Cooling System

For optimum protection, drain, flush, and refill the cooling system at the interval listed in the operation manual's service schedule.

Pay special attention to the coolant level. Check the coolant level as described earlier.

Flush and Clean Procedure

1. Remove the pipe plug located in the heat exchanger.
2. Open the petcocks on the engine block and cooling system and let the system drain completely. Some models may have petcocks located behind the belt guard.
3. Remove the pressure cap to simplify draining.
4. Drain, clean, and flush the cooling system, including the coolant recovery tank, with clean water.
5. Close the petcocks.
6. Fill the cooling system with recommended coolant.

5.6 Pressure Cap

Closed heat exchanger systems utilize a pressure cap to raise the boiling point of the coolant, enabling higher operating temperatures. If the cap leaks, replace it with a cap having the same temperature rating.

5.7 Impeller Inspection and Replacement

The belt-driven seawater pump is located on the service side of the generator set. Check and change the seawater pump impeller at the interval specified in the service schedule. Follow the instructions included with the impeller kit. If the instructions are not included with the kit, use the following procedure.

Inspection and Replacement Procedure

1. Close the seacock.
2. Remove the seawater pump coverplate. See Figure 5-4.
3. Remove the impeller.
4. Inspect the impeller for damage, including visible cracked, broken, worn or missing fins. The impeller vanes should be straight and flexible. See Figure 5-5.
5. Lubricate the impeller with soapy water before re-installation.
6. While installing the impeller, always rotate the drive shaft and the impeller together in the same direction as the engine rotation.
7. Inspect the coverplate and gasket for corrosion and/or damage. Replace damaged or worn components.
8. Lubricate the gasket with silicon grease and attach the gasket and coverplate to the seawater pump housing.

9. Open the seacock.
10. Start the generator set and check for leaks.
11. Stop the generator set and repair leaks or replace components as necessary.




Figure 5-4 Seawater Pump, Typical




Figure 5-5 Worn Impeller

5.8 Belt Tension

⚠ WARNING
<p>Rotating parts. Can cause severe injury or death.</p> <p>Operate the generator set only when all guards, screens, and covers are in place.</p>

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Check the belt tensions at the interval specified in the service schedule. If the tensions are not within specifications, adjust as necessary using the following procedure.

Belt Tensioning Procedure

1. Stop the generator set.
2. Disconnect the generator set engine starting battery, negative (-) lead first.
3. Remove the belt guard.
4. Check the belt tension at the midpoint of the longest span of the belt by pressing the belt with your finger and measuring the resulting deflection. See Figure 5-6 and Figure 5-7. If the belt is not within specifications, go to step 5. If the belt is within specifications, go to step 9.
5. Loosen the adjusting arm pivot screw, alternator pivot screw, and alternator adjusting screw.
6. While prying the alternator outward, tighten the alternator screw.

7. Tighten the adjusting arm pivot screw and alternator pivot screw.
8. Recheck and adjust the belt tension as necessary.
9. Replace the belt guard.
10. Reconnect the generator set engine starting battery, negative (-) lead last.

Belt Type	Deflection mm (in.)	Force (kgf) N
New	(7-9) 0.3-0.4	(10) 98
Used	(10-15) 0.4-0.6	(10) 98

Figure 5-6 Belt Specifications




Figure 5-7 Belt Tension, Typical

5.9 Siphon Break

A siphon break prevents seawater entry into the engine when the engine exhaust manifold outlet is less than 23 cm (9 in.) above waterline. Check the siphon break at the interval listed in the service schedule. Use the following procedure and Figure 5-8 to ensure correct functioning of the siphon break.

Siphon Break Inspection Procedure

1. Stop the generator set.
2. Remove the retaining cap and the reed valve for inspection. See Figure 5-8.

3. Use a light detergent to clean the reed valve.
4. Check that the reed valve opening is clear.
5. Replace the siphon break if it is cracked or if the reed valve material has hardened or deteriorated.
6. Install the reed valve downward into the mounting base.
7. Install the retaining cap and finger-tighten only. Do not over-tighten.

Note: Consult the installation manual for a complete explanation of the dimensions and other installation considerations.




Figure 5-8 Siphon Break, Plastic "U" Type

5.10 Anticorrosion Zinc Anode

The heat exchanger contains an anticorrosion zinc anode (plug) to prevent electrolytic corrosion of generator components by seawater.

Check and replace the zinc anode at intervals recommended by the operation manual's service schedule.




Figure 5-9 Anticorrosion Zinc Anode

Anticorrosion Zinc Anode Replacement Procedure

1. With the generator set cooled, close the seacock, remove the zinc plug from the heat exchanger, and drain the coolant into a container.
2. Remove the corrosion on the zinc anode. Replace the anode when the percent of the zinc remaining is less than 50% of the length and diameter shown in Figure 5-10.
3. Clean the threaded opening of the heat exchanger and coat the threads of the zinc anode with pipe sealant.
4. Install the zinc anode into the heat exchanger.
5. Open the seacock.
6. Refill the cooling system.
7. Start the generator set and check for leaks at the zinc anode's location. The pump is operating if cooling water flows from the exhaust outlet. If water is not discharging at the exhaust outlet stop the generator set. For seawater pump priming see the Prestart Checklist in the operation manual.




Figure 5-10 Anticorrosion Zinc Anode (Plug)

Section 6 Controller Troubleshooting

6.1 General

The following section covers the controller troubleshooting procedure for generator sets equipped with the relay controller and related engine components. Refer to Figure 6-1 to identify the controller components.




Figure 6-1 Controller Internal Components

6.2 Controller Sequence of Operation

The following text covers the controller's sequence of operation during generator start, run, stop, and fault

shutdown modes. Use this as a starting point for controller fault identification. Use the LEDs on the controller circuit board to assist in the troubleshooting process. An illuminated LED indicates that the respective relay is receiving power; the LED does not indicate whether that relay is energized. Additional relay test procedures are covered later in this section. Refer to the wiring diagrams in Section 10, Voltage Reconnection and Wiring Diagrams, to assist in the troubleshooting procedure.

6.2.1 Start

Close the start/stop switch between N (ground) and 47 (local or remote starting).

The K2 relay energizes. The normally open K2 contacts close to energize the K3 relay (LED3 lights), the K25 (fuel solenoid) relay, the controller hourmeter, and the generator armature exciter field.

The K25 relay normally open contacts close to energize the fuel solenoid.

The K3 relay normally open contacts close to energize the K20 (starter) relay. The K20 relay normally open contacts close to energize the S relay (starter solenoid). The S relay normally open contacts close to energize the starter motor.

6.2.2 Run

The B1 and B2 windings of the stator supply AC voltage to the bridged rectifier (BR1), the K1 relay energizes (LED1 lights). After a 5–10 second time delay, the K5 relay energizes (LED5 lights).

Note: Voltage to the K1 and K5 relays is rectified and regulated at 12 volts DC by the bridge rectifier (BR1) and the voltage regulator (VR1).

Stator winding 33–34 provides a voltage sensing source to the voltage regulator (PBIIE).

The normally open K1 contacts close to maintain voltage to the K2 relay (LED2 remains lit).

The normally open K2 contacts remain closed to maintain voltage to the fuel solenoid and the controller hourmeter.

The normally open K1 contacts close to energize the (optional) oil pressure, coolant temperature, battery voltmeter, and hourmeter gauges and the generator ON light.

The normally open K5 contacts close to permit the high water temperature (HWT), high exhaust temperature (HET), and low oil pressure (LOP) switches to function.

Note: The low oil pressure (LOP) switch contacts open when the engine develops oil pressure.

One set of normally closed K1 contacts opens to disconnect the circuit to the positive (+) connection of the exciter fields (field flashing).

A set of normally closed K1 contacts opens to disconnect the circuit to the negative (-) connection of the exciter field (field flashing). The normally closed K1 contacts open to deenergize the K3 relay (LED3 goes out) and prevent accidental reenergizing of the starter motor. The K3 contacts open to deenergize the K20 relay. The K20 contacts open to deenergize the S relay. The S contacts open to deenergize the starter motor.

When the generator set is running, the start switch contacts N and 47 open by releasing the start/stop rocker switch.

6.2.3 Stop

Close the start/stop switch between N and 43 (local or remote).

The K4 relay energizes (LED4 lights).

The normally closed K4 contacts open to deenergize the K25 relay. The K25 normally open contacts open to deenergize the fuel solenoid.

The normally open K4 contacts close to maintain ground to the K4 relay.

As the generator set shuts down, the K1 relay deenergizes (LED 1 goes out). The normally open K1 contacts open to deenergize the K2 relay (LED 2 goes out). The normally closed K2 contacts close to ground the circuit to the K4 relay until the generator set comes to a complete stop.

6.3 Engine Safety Shutdown Switches

6.3.1 Low Oil Pressure (LOP) Shutdown

When low oil pressure occurs, the LOP shutdown switch contacts close and energize the K4 relay (LED4 lights).

Note: During cranking the low oil pressure shutdown switch is deactivated until the K5 relay energizes. This delay allows the engine to reach normal operating oil pressure. The normally closed LOP contacts open when the generator set develops adequate oil pressure.

The normally closed K4 contacts open to deenergize the K25 relay. The K25 normally open contacts open to deenergize the fuel solenoid.

The normally open K4 contacts close to maintain ground to the K4 relay.

As the generator set shuts down, the K1 relay deenergizes (LED1 goes out). The normally open K1 contacts open to deenergize the K2 relay (LED2 goes out). The normally closed K2 contacts close to ground the circuit to the K4 relay until the generator set comes to a complete stop.

6.3.2 High Water Temperature (HWT) and High Exhaust Temperature (HET) Shutdown Switch

When a high temperature is encountered at one (or both) of these sources, the shutdown switch contacts close and energize the K4 relay (LED4 lights).

The normally closed K4 contacts open to deenergize the K25 relay. The K25 normally open contacts open to deenergize the fuel solenoid.

The normally open K4 contacts close to maintain ground to the K4 relay.

As the generator set shuts down, the K1 relay deenergizes (LED1 goes out). The normally open K1 contacts open to deenergize the K2 relay (LED2 goes out). The normally closed K2 contacts close to ground the circuit to the K4 relay until the generator set comes to a complete stop.

Component	Ohmmeter Connections	Procedure	Results
K1 Relay Coil	K1 coil terminals (see relay schematic)	Ohmmeter on R x 10 scale	If functional, approximately 270 ohms. Low resistance (continuity), shorted coil. High resistance, open coil.
K2 Relay Coil	K2 coil terminals (see relay schematic)	Ohmmeter on R x 10 scale	If functional, approximately 270 ohms. Low resistance (continuity), shorted coil. High resistance, open coil.
K3 Relay Coil	K3 coil terminals (see relay schematic)	Ohmmeter on R x 10 scale	If functional, approximately 400 ohms. Low resistance (continuity), shorted coil. High resistance, open coil.
K4 Relay Coil	K4 coil terminals (see relay schematic)	Ohmmeter on R x 10 scale	If functional, approximately 125 ohms. Low resistance (continuity), shorted coil. High resistance, open coil.
K5 Relay Coil	K5 coil terminals (see relay schematic)	Ohmmeter on R x 10 scale	If functional, approximately 510 ohms. Low resistance (continuity), shorted coil. High resistance, open coil.

Figure 6-2 Relay Testing

6.4 Controller Circuit Board

Some controller circuit board components can be tested without removing the component from the circuit board. Perform these checks prior to installing a new circuit board and attempting startup. Use a high-quality multimeter and follow the manufacturer's instructions. To obtain accurate readings when testing, remove all the circuit board connectors and conformal coating (transparent insulation) from component terminals. Use the chart in Figure 6-2 and the controller circuit board illustration in Figure 6-3.

The controller circuit board has light-emitting diodes (LEDs) which indicate relay coil power and aid in the circuit board and the generator fault detection. When the K1, K2, K3, K4, or K5 relays receive power the corresponding LED lights. The LED does not indicate whether the relay coil is energized. Determine if the relay coil is energized by analyzing the generator faults when performing a continuity test on the relay coil.




Figure 6-3 Controller Circuit Board

6.5 Troubleshooting

Use the following flow chart as an aid in troubleshooting the main circuit board and the entire generator set. If the

prescribed remedy does not correct the problem, the circuit board may have to be replaced.




Figure 6-4 Troubleshooting Relay Controller Circuit Board (1 of 4)




Figure 6-5 Troubleshooting Relay Controller Circuit Board (2 of 4)




Figure 6-6 Troubleshooting Relay Controller Circuit Board (3 of 4)





Figure 6-7 Troubleshooting Relay Controller Circuit Board (4 of 4)

Section 7 Generator Troubleshooting

7.1 General

Before beginning the following troubleshooting procedures, read all the safety precautions at the beginning of this manual. The following tests include additional safety precautions; OBSERVE THESE PRECAUTIONS!



Testing the voltage regulator. Hazardous voltage can cause severe injury or death. High voltage is present at the voltage regulator heat sink. To prevent electrical shock do not touch the voltage regulator heat sink when testing the voltage regulator.

(PowerBoost™, PowerBoost™ III, and PowerBoost™ V voltage regulator models only)

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

High voltage test. Hazardous voltage can cause severe injury or death. Follow the instructions of the test equipment manufacturer when performing high-voltage tests on the rotor or stator. An improper test procedure can damage equipment or lead to generator set failure.

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

7.2 General Troubleshooting

To determine the cause of no- or low-AC output, refer to the following steps and the troubleshooting flow chart (Figure 7-1).

General Troubleshooting Procedure

1. Check the condition of the voltage regulator's 8-amp fuse.
2. If the fuse is functional, separately excite the generator. (See Section 7.3.) The separate excitation test duplicates the role of the voltage regulator by providing excitation current to the rotor.




Figure 7-1 General Troubleshooting

7.3 Separate Excitation

By separately exciting the generator to determine the presence of a faulty voltage regulator, it is possible to determine if a running fault exists in the rotor and/or stator. A generator component that appears functional while static (stationary) may exhibit a running open or short circuit while dynamic (moving). Centrifugal forces acting on the windings during rotation or insulation breakdown as temperatures increase can cause short circuits.

Separate Excitation Procedure

1. Disconnect all the leads from the voltage regulator.
2. Disconnect the P10 (F1, F2) connector.
3. Connect a separate excitation circuit as shown in Figure 7-2. Connect an ammeter and a 10-amp fuse in series with F1. Note and record the ammeter reading.
4. The approximate ammeter reading should equal battery voltage divided by the specified exciter resistances (cold). Disconnect the resistor leads and determine the resistance value using an ohmmeter. See Section 1, Specifications, for the correct values.

Example:

$$\frac{12 \text{ Volts (Battery Voltage)}}{3.5 \text{ Ohms Exciter Resistance}} = 3.4\text{-amp Exciter Current}$$




Figure 7-2 Separate Excitation Connections

5. Start the engine and check that the ammeter remains stable. An increasing meter reading indicates a shorted rotor. A decreasing meter reading to zero or unstable reading, suggests a running open in the rotor. If the ammeter is stable, continue with step 6.
6. Check for AC output across the stator leads and compare the measured output to the values in Section 1, Specifications. If the output varies considerably from those listed, a faulty stator, rotor, rectifier module, or armature is the likely cause.

Note: See Section 1, Specifications, for the stator output voltages (with separately excited generator). These specifications are based on a battery of 12 volts. Should the battery voltage vary, the resulting stator output values will also vary.

If there is no generator output during normal operation but output is available when the generator set is separately excited, the voltage regulator is probably inoperative.

7.4 PowerBoost III E Voltage Regulators

The generator set is equipped with a PowerBoost™ III E voltage regulator. See Figure 7-3.

The voltage regulator monitors the output voltage to the generator exciter field.

If the regulator's 8-amp fuse blows, the generator set will shut down. Verify that the regulator fuse is functional before proceeding with the test.




Figure 7-3 PowerBoost™ III E Voltage Regulator

7.4.1 Voltage Regulator Test

When the frequency drops below 57.5/47.5 Hz, the AC voltage should decline. Perform the following test to check the regulator output.

Use the following components to test the voltage regulator:

- Variable transformer, 0-140 volts, 0.5-amp minimum
- Plug, 120 volts AC
- Lamp, 120 volt, 100 watt
- AC voltmeter
- Insulated copper wire, #14 AWG, minimum

Regulator Test Procedure

1. Connect the components as shown in Figure 7-4.
2. Turn the variable transformer setting to zero. Plug in the variable transformer.
3. Turn the variable transformer on. Slowly increase the variable transformer voltage to 100 volts. The test lamp should light. If the lamp does not light, turn the voltage adjustment potentiometer (pot) clockwise. If the lamp still does not light, the voltage regulator is inoperative. Replace the voltage regulator. An inoperative voltage regulator causes a generator no/low-output condition.
4. Slowly increase the voltage to 120 volts. The lamp should go out and stay out as the voltage increases. If the lamp remains lit, turn the voltage adjustment pot counterclockwise. If the lamp still remains lit, replace the voltage regulator. An inoperative voltage regulator causes a generator high voltage output condition.
5. Turn the variable transformer to zero and unplug the AC cord.

Note: For applications requiring fine voltage adjustment, connect a remote rheostat to voltage regulator terminal 66.




Figure 7-4 PowerBoost™ III E Voltage Regulator Test

7.4.2 Voltage Regulator Adjustment

Kohler Co. sets the voltage regulator and, under normal circumstances, the regulator requires no further adjustment. However, if the voltage regulator has been replaced or tampered with, or if voltage/frequency reconnection has been done, readjust the voltage regulator according to the following procedure. The following paragraphs describe the voltage regulator components.

Voltage Adjustment Pot adjusts the generator output within the range of 100-130 volts.

Stabilizer Pot fine-tunes regulator circuitry to reduce light flicker.

Volts/Hz Pot adjustment determines the engine speed (Hz) at which the generator output voltage begins to drop.

Note: The **volts/Hz** adjustment does not apply to the following models: 4/6.5/8/9EFOZ and 5/8/9/10EOZ. On these models, turn the volts/Hz adjustment pot full counterclockwise to stop and seal. No further volts/Hz adjustments are required.

Voltage Regulator Adjustment Procedure

1. Stop the generator set.
2. Turn the remote rheostat, if equipped, to the midpoint. Turn the **voltage** and **stability pots** fully counterclockwise. Connect the voltmeter to the AC circuit or an electrical outlet.
3. Start the generator set.
4. Adjust the engine speed to 1800 rpm on 60 Hz units and 1500 rpm on 50 Hz units.
5. Rotate the **voltage adjustment pot** clockwise to increase the voltage or counterclockwise to decrease the voltage to achieve the desired output voltage.
6. Rotate the **stability pot** clockwise until the light flickers minimally.
7. Readjust the **voltage adjustment pot** to achieve the desired output voltage.




Figure 7-5 PowerBoost™ IIIIE Voltage Regulator Adjustment

8. Use the remote rheostat, if equipped, to make final voltage adjustments.
9. Stop the generator set.

7.5 Exciter Field

DC current from the battery magnetizes the exciter field. When the exciter armature rotates within the magnetized exciter field windings, an electrical current develops within the exciter armature. There will be low or no generator output if the exciter field is inoperative. Test the exciter field according to the following procedure.

Exciter Field Test Procedure

1. Place the start/stop switch in the STOP position.
2. Disconnect the generator set engine starting battery, negative (-) lead first.
3. Disconnect the P6 and P7 connectors.
4. Check the exciter field resistance by connecting an ohmmeter across exciter field FP and FN leads. See Section 1, Specifications, for the resistance reading of a cold exciter field. A low reading indicates an internal short and a high reading indicates an open winding. Repair or replace the exciter field if the ohmmeter readings indicate an inoperative exciter field. If the resistance test proves inconclusive, perform a megohmmeter test on the exciter field as described in the next step.




Figure 7-6 Exciter Field Resistance Check

5. Check the exciter field for a grounded condition. Use a megohmmeter to apply 500 volts DC to the FP or FN lead and the exciter field frame. Follow the instructions of the megohmmeter manufacturer when performing this test. A reading of approximately 500 kOhms (1/2 megohm) and higher indicates the field winding is functional. A reading of less than approximately 500 kOhms indicates deterioration of the winding insulation and possible current flow to ground. Repair or replace the exciter field.




Figure 7-7 Megohmmeter Connections on the Exciter Field

7.6 Exciter Armature

The exciter armature supplies excitation current to the generator main field through the rectifier module. There will be low or no generator output if the exciter armature is inoperative. Test the exciter armature as described in the following steps. Disassemble the generator set prior to performing this test.

Exciter Armature Test Procedure

1. Disassemble the alternator.
2. Disconnect the armature leads from the rectifier module AC terminals.
3. With an ohmmeter on the R x 1 scale, check the resistance across the exciter armature leads. See Figure 7-8. The armature resistance should be 0.6–0.8 ohms (continuity). No continuity indicates an open armature winding. Replace the armature.
4. Perform a megohmmeter test on the exciter armature as described in the next step. Consider the exciter armature good if the resistance reading (continuity) is low and there is no evidence of a shorted winding (heat discoloration).




Figure 7-8 Exciter Armature Ohmmeter Test

5. Check if the exciter armature winding is ground. Use a megohmmeter to apply 500 volts DC to either armature lead and the armature frame. Follow the instructions of the megohmmeter's manufacturer when performing this test. See Figure 7-9. A reading of approximately 500 kOhms (1/2 megohm) and higher indicates that the exciter armature is functional. A reading of less than approximately 500 kOhms indicates deterioration of the winding insulation and possible current flow to ground. Repair or replace the exciter armature.




Figure 7-9 Megohmmeter Connections on Exciter Armature

7.7 Rectifier Module

The rectifier module, located between the exciter armature and the main field, converts the AC from the exciter armature to DC which magnetizes the generator main field. Test the rectifier module as described in the following steps.

Rectifier Module Test Procedure

1. Disconnect the exciter armature and the main field leads from the rectifier module.
2. Use an ohmmeter on the R x 100 scale to check the resistance between the rectifier diodes as shown in Figure 7-10. The ohmmeter should show resistance in one direction and, upon reversing the ohmmeter leads, a high resistance in the other direction. Replace the rectifier module if any of the diodes tests differently than described.




Figure 7-10 Testing Rectifier Module

7.8 Rotor

The generator rotor (magnetized by DC current from the rectifier module) rotating within the stator windings induces AC voltage in the stator windings. Test the generator rotor (main field) as described in the following steps.

Rotor Test Procedure

1. Disassemble the generator.
2. Disconnect the generator main field windings from rectifier module terminals F+ and F-.
3. Check the main field resistance by connecting an ohmmeter across the main field F+ and F- leads. See Figure 7-11. The resistance reading for a cold main field should be approximately 2.5-4.5 ohms. A low reading indicates an internal short and a high reading indicates an open winding. Replace the main field if the ohmmeter readings indicate that the main field is inoperative.
4. Perform a megohmmeter test on the main field as described in the next step.




Figure 7-11 Ohmmeter Connections on Main Field

5. Check the main field for a grounded condition by using a megohmmeter. Apply 500 volts DC to either field lead and the main field frame. Follow the instructions of the megohmmeter's manufacturer when performing this test. See Figure 7-12. A reading of approximately 500 kOhms (1/2 megohm) and higher indicates the main field is good. A reading of less than approximately 500 kOhms indicates the deterioration of the winding insulation and possible current flow to ground. Repair or replace the main field.




Figure 7-12 Megohmmeter Connections on Main Field

7.9 Stator

The stator consists of a series of coils of wire laid in a laminated steel frame. The stator leads supply voltage to the AC load and exciter regulator.

Leads 1, 2, 3, and 4 are the generator output leads. Leads 33, 44, and 55 are the voltage regulator supply and sensing leads. The output of leads B1 and B2 are rectified by BR1 to supply the control voltage. BR1 is located on the controller circuit board.

Prior to testing, inspect the stator for heat discoloration and visible damage to the housing lead wires or exposed and varnished areas of the frame laminations. Be sure the stator is securely fastened in the stator housing.

The stator produces electrical output (AC) as the magnetized main field rotates within the stator windings. Test the condition of the stator according to the following procedure. Refer to the schematic in Figure 7-13 when performing the following tests.

Stator Test Procedure

1. Check the generator output lead connections. See Section 10, Voltage Reconnection and Wiring Diagrams.
2. Disconnect all the stator leads to isolate the windings. To check the stator continuity, set the ohmmeter on the R x 1 scale. Contact the red and black ohmmeter leads; adjust the ohmmeter to zero ohms. Check the stator continuity by connecting the meter leads to the stator leads as shown in Figure 7-13. Perform the stator tests on all the stator windings. See Figure 7-14.
3. Contact the ohmmeter leads and readjust the ohmmeter to zero ohms. Check the cold resistance of the stator windings by connecting the meter leads to the stator leads 1 and 2, 3 and 4, B1 and B2, etc. See Section 1, Specifications, for the stator resistance values. Replace the stator if readings do not fall within the specified value.

Note: The stator resistance will vary directly with increased temperature.




Figure 7-13 Stator Ohmmeter Connections

Between Leads	Continuity
1 and 2	Yes
3 and 4	Yes
33 and 44	Yes
33 and 55	Yes
B1 and B2	Yes
1 and 3, 4, 33, 44, 55	No
1 and 55, B1, and B2	No
4 and B1 and B2	No
55 and B1 and B2	No
Any stator lead and ground	No

Figure 7-14 Stator Continuity

- Perform a megohmmeter test on the stator as described in the next step. Consider the stator good if the resistance reading (continuity) is low and there is no evidence of shorted windings (heat discoloration).

Note: When taking an ohmmeter reading using lead 55, make the connection prior to the in-line fuse.

- Check the stator for a short to ground using a megohmmeter. Apply 500 volts DC to any stator lead from each winding and the stator frame. Follow the instructions of the megohmmeter manufacturer when performing this test. Repeat the test on the other leads until all the stator windings have been tested. A reading of approximately 500 kOhms (1/2 megohm) and higher indicates the stator is good. A reading of less than approximately 500 kOhms indicates deterioration of the winding insulation and possible current flow to ground. Repair or replace the stator.





Figure 7-15 Megohmmeter Connections on Stator

Section 8 Component Troubleshooting

8.1 General

See Figure 8-1 through Figure 8-3 for component testing. With the generator set battery connected, check the generator wiring harness and the components listed in the following tables. Check each component using a multimeter to verify that the switches function and that voltage is present at each component.

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.



Component	Voltmeter Connections	Procedure	Results
Hourmeter and wiring	Connect the red test lead to the hourmeter positive (+) terminal. Connect the black test lead to the hourmeter negative (-) terminal.	Set the voltmeter to 12 volts DC or greater. Start the generator set.	A 12 volt DC reading indicates the wiring harness is functional.
	None (see Procedure).	Disconnect the hourmeter leads and apply 12 volts DC to the hourmeter. The hourmeter is polarity sensitive.	If functional, hourmeter operates.
Stator auxiliary winding B1 and B2	Connect the AC voltmeter leads to the B1 and B2 windings at connector P11.	Stop the generator set. Connect a voltmeter to the B1 and B2 windings. Crank the generator set and allow the set to reach rated its speed.	A reading of 12-15 volts AC indicates a functional B1/B2 winding.

Figure 8-1 Engine/Generator Component Testing, Relay Controller

To further check the generator set components, disconnect the battery and remove the wiring harness plugs from the controller circuit board. Use an ohmmeter to check the continuity of the components and to isolate inoperative components. Refer to Figure 8-2 and Figure 8-3.

Note: Before performing ohmmeter checks, disconnect the generator set battery to prevent damage to the ohmmeter.

Component	Ohmmeter Connections	Procedure	Results
Start/stop switch	Connect the ohmmeter to the P2-6 and P2-4 leads.	Place the ohmmeter on the R x 1000 scale. Place the rocker switch in the START position.	If the switch is functional, zero ohms continuity. Any resistance other than zero or very low ohms, replace the switch.
	Connect the ohmmeter to the P2-6 and P2-5 leads.	Place the ohmmeter on the R x 1000 scale. Place the rocker switch in the STOP position.	If the switch is functional, zero ohms continuity. Any resistance other than zero or very low ohms, replace the switch.
K20 relay coil and wiring	Connect the ohmmeter to the P1-4 and P1-9 leads.	Place the ohmmeter on the R x 1 scale.	If functional, 85 ohms. Low resistance, shorted C relay coil and/or wiring. High resistance, open C relay and/or wiring. Replace the controller board.
Starter solenoid (S relay)	Connect the ohmmeter to the P4-22 lead and the battery positive (+) cable. Note: The J4 and P4 leads must be disconnected to perform this test.	Place the ohmmeter on the R x 1 scale.	If functional, approximately 0.5-0.6 ohms at 27°C (80°F).
Controller 10-amp circuit breaker and wiring	Connect the ohmmeter to the battery positive (+) cable and the P1-14 lead. Note: The J4 and P4 leads must be connected to perform this test.	Place the ohmmeter on the R x 1000 scale.	If functional, zero or very low ohms. No reading (infinity), open circuit or circuit breaker tripped.

Figure 8-2 Engine/Generator Component Testing, Relay Controller

Component	Ohmmeter Connections	Procedure	Results
Main field (rotor)	Disconnect the P10 and P11 connectors and connect the ohmmeter to P10-1 and P10-2 leads.	Place the ohmmeter on the R x 1 scale.	If the resistance readings match those specified in Section 1, Specifications, the rotor is functional. Low resistance, rotor windings shorted. High resistance, rotor windings open.
B1/B2 stator windings	Connect the ohmmeter to the P11-1 and P11-2 leads. Note: Disconnect P11 and J11 to perform this test.	Place the ohmmeter on the R x 1 scale.	If the resistance readings match those specified in Section 1, Specifications, the B1/B2 windings are functional. Low resistance, B1/B2 windings shorted. High resistance, B1/B2 windings open.
P1 ground connection	Connect the ohmmeter to the P1-9 and ground.	Place the ohmmeter on the R x 1 scale.	If functional, zero ohms (continuity). Any other reading indicates a poor ground connection.
High exhaust temperature (HET), low coolant (LCS) safety shutdown switches	Connect the ohmmeter to the P1-15 and engine block (ground). Note: Remove and isolate the LOP switch lead.	Place the ohmmeter on the R x 1000 scale.	If functional, open circuit. Any continuity suggests an inoperative temperature switch(es). Replace the switch(es).
Low oil pressure (LOP) safety shutdown switch	Connect the ohmmeter to the P13-1 and engine block (ground).	Place the ohmmeter on the R x 1000 scale. This test is not conclusive until the temperature shutdown switches are checked.	If functional, zero ohms (continuity). Then, disconnect the LOP switch lead and isolate the terminal. Meter reading should show an open circuit.

Figure 8-3 Engine/Generator Component Testing, Relay Controller

8.2 Remote Panels (Optional)

Kohler Co. offers three remote panels for connection to the generator set:

- A panel with a start/stop switch
- A panel with a start/stop switch and two gauges (engine oil pressure and water temperature)
- A panel with a start/stop switch and four gauges (DC voltmeter, engine oil pressure, water temperature, and hourmeter)

If difficulty with the remote operation occurs, test the switch, gauges, and gauge senders using the following procedures. See Sections 10.5 through 10.7 for wiring diagrams.

Troubleshooting Remote Start Panels

Generally, if the sender changes its resistance values as its respective pressure/temperature changes, it is working correctly. An inoperative sender will either be open or shorted. Refer to Figure 8-4 and Figure 8-5 for resistance values.

2-Meter and 4-Meter Panels	
Temperature	Resistance
60°C (140°F)	134.0 ±10 ohms
90°C (194°F)	51.5 ±4 ohms
100°C (212°F)	38.0 ±3 ohms

Figure 8-4 Water Temperature Sender Resistance

2-Meter and 4-Meter Panels	
Pressure	Resistance
0 kPa (0 psi)	10 ohms
345 kPa (50 psi)	80 ohms
690 kPa (100 psi)	135 ohms

Figure 8-5 Oil Pressure Sender Resistance

Refer to Figure 8-6 for troubleshooting information on the remote start panels.

Component	Ohmmeter Connections	Procedure	Results
Remote start/stop switch	Remote switch: yellow/red wire terminal and black wire terminal.	Place the ohmmeter on the R x 1 scale. Press the rocker switch to the START position.	Continuity, the switch is functional. Open, replace switch.
	Remote switch: grey/black wire terminal and black wire terminal.	Place the ohmmeter on the R x 1 scale. Press the rocker switch to the STOP position.	Continuity, the switch is functional.
Generator set ON light, gauge lights, DC voltmeter, and hourmeter	Connect the red test lead to P3-4 and black test lead to P3-1.	Place the controller rocker switch to the START position. Stop the generator set when the test is complete. Generator set does not need to be running, just cranking for this test. Note: If the hourmeter is not illuminated, test it by connecting it to a 12-volt battery. Note: The hourmeter is polarity sensitive.	If 12-volts DC is present and the component does not function after the J3 is connected to the controller P3, replace the component(s).
Water temperature gauge	Connect the red test lead to P3-4 (socket side) and black test lead to P3-2 (socket side).	Start the generator set for the test.	If 0.5-12-volts DC is present and the gauge does not function after the J3 is connected to controller, replace the gauge.
Oil pressure gauge	Connect the red test lead to P3-4 (socket side) and black test lead to P3-3 (socket side).	Start the generator set for the test.	If 0.5-12-volts DC is present and the gauge does not function after the J3 is connected to the controller, replace the gauge.
Note: Check continuity of gauge wiring and extension harness before replacing components.			

Figure 8-6 Remote Start Panels Troubleshooting

Section 9 Generator Disassembly/Reassembly

9.1 Disassembly

Disconnect all the external connections—battery cables at the battery (negative (-) lead first), AC-output leads in the controller, remote start panel at the controller P3 connector, water line at the seawater pump, fuel line at the fuel pump filter inlet, and exhaust line at the mixing elbow. Observe all the safety precautions listed at the beginning of this manual during the disassembly/reassembly procedures.

Note: Because this manual covers several models, the procedure for disassembly may vary because of product updates and the assembly variations.

Note: The voltage regulator is located in the controller box. Remove the controller cover to service the voltage regulator. Adjustments are possible without removing the voltage regulator from the controller.

8. Remove the tie wraps from the wire harness as necessary. Disconnect the F1 connectors from the resistor leads.




Figure 9-1 Covers

1. Remove the end panel from the alternator end of the generator set. See Figure 9-1.
2. Loosen the four screws and lift off the controller cover.
3. Disconnect the P4 (22-pin) connector from J4.
4. Remove the bolt and disconnect the ground strap.

Note: It is possible to connect the output leads in various positions for different volt configurations. Mark leads 1, 2, 3, and 4 for correct reconnection.

5. Disconnect the generator output leads 1, 2, 3, and 4 from the circuit breaker and neutral stud (L0).
6. Remove the four controller mount locknuts. See Figure 9-2.
7. Lift the controller from the rubber mounts while guiding the leads through the bottom hole of the controller box.




Figure 9-2 Controller Removal

9. Disconnect the P7 (FP and FN) and P6 (F1 and F2) connectors. See Figure 9-3.
10. Remove the four bolts to remove the exciter field. See Figure 9-3.
11. Remove the three bolts and spacers from the rectifier board.




Figure 9-3 Exciter Field Removal




Figure 9-4 Armature Removal

12. Disconnect the main field rotor leads from the rectifier board positive/negative terminals. Remove the bolt and washer.
13. Remove the armature from the shaft, guiding rotor leads through the armature bores. See Figure 9-4.
14. Remove the tie wraps and disconnect the P5 (33, 44, 55, B1, and B2) wire connector.
15. Attach the hoist hook to the generator hoisting eye.

Note: The hoist capacity rating should be one-half ton or greater.
16. Remove the two vibromount bolts. See Figure 9-5.
17. Raise the alternator end and place a wood block under the locator plate. Lower the alternator until the wood block supports the locator plate. See Figure 9-5.
18. Remove the four overbolts from the end bracket. See Figure 9-5.




Figure 9-5 Supporting the Generator

19. Install a sling on the stator housing. See Figure 9-6.
20. Use a two-jaw puller to pull the end bracket/stator assembly from the bearing on the rotor shaft. See Figure 9-6.
21. Remove the stator assembly from the rotor. Remove or rotate the fan guard, if necessary, to clear the vibromounts.
22. Remove the four locknuts and remove the fan and fan spacer. See Figure 9-7.
23. Remove the six metric bolts to remove the drive disc/rotor assembly from the engine flywheel. See Figure 9-7.
24. Clamp the rotor in a soft-jaw vise. Remove the eight bolts and remove the drive disc assembly from the rotor. See Figure 9-8.




Figure 9-6 Stator Assembly Removal

9.2 Reassembly

1. Clamp the rotor in a soft-jaw vise. Install the drive disc on the rotor with disc studs facing the rotor. Tighten the eight bolts to 40 Nm (30 ft. lbs.). See Figure 9-8.
2. Install the rotor/drive disc assembly on the engine flywheel using six washers and bolts. Tighten the bolts to 27 Nm (20 ft. lbs.).
3. Install the fan to the drive disc using four spacers, washers, and locknuts.

Note: Install the fan with the flange side facing away from the flywheel. Space the studs so that they allow the fan installation in one position only.




Figure 9-7 Disc/Rotor and Fan Assembly




Figure 9-8 Drive Disc

4. Inspect the O-ring in the end bracket bearing bore and replace the O-ring if damaged. Use a sling to support the stator assembly while installing the stator over the rotor. Be careful not to damage the rotor. See Figure 9-9.
5. Install the four overbolts (the two long bolts in the lower holes). Check that the alignment marks on the stator housing and locator plate match. See Figure 9-10. Tighten the overbolts to 40 Nm (30 ft. lbs.).




Figure 9-9 Stator Installation




Figure 9-10 Alignment Marks

6. Use the hoist to raise the alternator end. Remove the wood block from under the locator plate. Lower the generator set and install a bolt, a large washer, two small washers, and a locknut in each vibromount. Tighten the mounting bolts to 28 Nm (20 ft. lbs.).
7. Apply antiseize compound to the keyed end of the rotor shaft. Bring the rotor leads through the bores in the armature while installing the armature on the shaft. Check the keyway of the shaft and key of the armature for damage. Install the armature retaining bolt and washer.

8. Use screws and lock washers to install the rotor leads to the rectifier board at the positive (+) and negative (-) terminals.

Note: Position the lock washers against the rectifier board.

9. Install three spacers and bolts to mount the rectifier board to the armature.
10. Install the exciter field using four bolts and washers. The field leads are at the top. Connect the P6, P7, and F1 connectors. See Figure 9-11.




Figure 9-11 Installing Exciter Field

11. Install tie wraps to secure the wires as necessary.
12. Route output leads 1, 2, 3, and 4 through the bottom of the controller box. Check that the grommet is intact and there are no sharp edges exposed that could damage the wiring. Install the box on the rubber mounts and install the four locknuts. Connect the leads to the circuit breaker and neutral stud (LO) as marked during disassembly.

Note: Check the generator set's nameplate to verify the original voltage configuration. See Section 10, Voltage Reconnection and Wiring Diagrams, for more information regarding voltage reconnection.
13. Connect the P4 (22-pin) connector. Connect the ground strap using a bolt, washer, and lock washer (install the lock washer against the ground strap).
14. Install the controller cover.
15. Install the end panel with the louvered openings down.
16. Reconnect all the external connections—the exhaust line to the mixing elbow, the fuel line to the fuel pump filter inlet, the water line to the seawater pump, the remote start panel to the controller P3 connector, the AC output leads in controller, and the battery cables to the battery (negative (-) lead last).
17. Open the seacock and the fuel valve.

Section 10 Voltage Reconnection and Wiring Diagrams

10.1 Voltage Reconnection

The following information illustrates the proper reconnection of 4-lead generator sets. In all cases, follow the National Electrical Code (NEC).

NOTICE

Voltage reconnection. Affix a notice to the generator set after reconnecting the set to a voltage different from the voltage on the nameplate. Order voltage reconnection decal 246242 from an authorized service distributor/dealer.

10.1.1 100-120-Volt Configurations




Figure 10-1 100-120 Volt, 3 Wire

Do not connect the load-side terminals of the circuit breaker together when using a factory 2-pole circuit breaker. See Figure 10-1. If the installation requires a 100-120-volt, 2-wire system, use a 1-pole circuit breaker. See Figure 10-2. When connecting stator phase leads together, size the output lead (L1) accordingly. Use a jumper lead on the line side of the circuit breaker to balance the generator set load.




Figure 10-2 100-120 Volt, 2 Wire

10.1.2 100-120/200-240-Volt Configurations

This configuration does not use a jumper lead. If the unit was originally wired for straight 100-120 volt, 3 wire, remove the jumper lead (see Figure 10-1 and Figure 10-2 for location). Select a circuit breaker manufactured with a 2-pole circuit breaker. Two 1-pole circuit breakers do not conform to NEC requirements when supplying a 200-240-volt load. This is true even if they are mechanically attached together. Since leads L1 and L2 are different phases, *never* connect them together.




Figure 10-3 100-120/200-240 Volt, 3 Wire

10.1.3 200-240-Volt Configurations

This configuration does not use a jumper lead. If the unit was originally wired for straight 100-200 volt, 3 wire, remove the jumper lead (see Figure 10-1 and Figure 10-2 for location).








Figure 10-4 200-240 Volt, 2 Wire

10.2 Marine Manual (Ship-to-Shore) Transfer Switch



Electro Switch



Kraus Naimler/American Solenoid (Early Rectangular Design)




Kraus Naimler/American Solenoid (Newer Round Design)




TP-5399-5


10.3 Wiring Diagram, Schematic




10.4 Wiring Diagram, Point-to-Point




10.5 Remote Start Panel



10.6 Remote Start and 2-Meter Panel



10.7 Remote Start and 4-Meter Panel



Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
A/D	analog to digital	CL	centerline	fglass.	fiberglass
ADC	analog to digital converter	cm	centimeter	FHM	flat head machine (screw)
adj.	adjust, adjustment	CMOS	complementary metal oxide substrate (semiconductor)	fl. oz.	fluid ounce
ADV	advertising dimensional drawing	cogen.	cogeneration	flex.	flexible
AHWT	anticipatory high water temperature	com	communications (port)	freq.	frequency
AISI	American Iron and Steel Institute	coml	commercial	FS	full scale
ALOP	anticipatory low oil pressure	Coml/Rec	Commercial/Recreational	ft.	foot, feet
alt.	alternator	conn.	connection	ft. lb.	foot pounds (torque)
Al	aluminum	cont.	continued	ft./min.	feet per minute
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	CPVC	chlorinated polyvinyl chloride	g	gram
AO	anticipatory only	crit.	critical	ga.	gauge (meters, wire size)
API	American Petroleum Institute	CRT	cathode ray tube	gal.	gallon
approx.	approximate, approximately	CSA	Canadian Standards Association	gen.	generator
AR	as required, as requested	CT	current transformer	genset	generator set
AS	as supplied, as stated, as suggested	Cu	copper	GFI	ground fault interrupter
ASE	American Society of Engineers	cu. in.	cubic inch	GND, 	ground
ASME	American Society of Mechanical Engineers	cw.	clockwise	gov.	governor
assy.	assembly	CWC	city water-cooled	gph	gallons per hour
ASTM	American Society for Testing Materials	cyl.	cylinder	gpm	gallons per minute
ATDC	after top dead center	D/A	digital to analog	gr.	grade, gross
ATS	automatic transfer switch	DAC	digital to analog converter	GRD	equipment ground
auto.	automatic	dB	decibel	gr. wt.	gross weight
aux.	auxiliary	dBA	decibel (A weighted)	H x W x D	height by width by depth
A/V	audiovisual	DC	direct current	HC	hex cap
avg.	average	DCR	direct current resistance	HCHT	high cylinder head temperature
AVR	automatic voltage regulator	deg., °	degree	HD	heavy duty
AWG	American Wire Gauge	dept.	department	HET	high exhaust temperature, high engine temperature
AWM	appliance wiring material	dia.	diameter	hex	hexagon
bat.	battery	DI/EO	dual inlet/end outlet	Hg	mercury (element)
BBDC	before bottom dead center	DIN	Deutsches Institut fur Normung e. V. (also Deutsche Industrie Normenausschuss)	HH	hex head
BC	battery charger, battery charging	DIP	dual inline package	HHC	hex head cap
BCA	battery charging alternator	DPDT	double-pole, double-throw	HP	horsepower
BCI	Battery Council International	DPST	double-pole, single-throw	hr.	hour
BDC	before dead center	DS	disconnect switch	HS	heat shrink
BHP	brake horsepower	DVR	digital voltage regulator	hsg.	housing
blk.	black (paint color), block (engine)	E, emer.	emergency (power source)	HVAC	heating, ventilation, and air conditioning
blk. htr.	block heater	EDI	electronic data interchange	HWT	high water temperature
BMEP	brake mean effective pressure	EFR	emergency frequency relay	Hz	hertz (cycles per second)
bps	bits per second	e.g.	for example (<i>exempli gratia</i>)	IC	integrated circuit
br.	brass	EG	electronic governor	ID	inside diameter, identification
BTDC	before top dead center	EGSA	Electrical Generating Systems Association	IEC	International Electrotechnical Commission
Btu	British thermal unit	EIA	Electronic Industries Association	IEEE	Institute of Electrical and Electronics Engineers
Btu/min.	British thermal units per minute	EI/EO	end inlet/end outlet	IMS	improved motor starting
C	Celsius, centigrade	EMI	electromagnetic interference	in.	inch
cal.	calorie	emiss.	emission	in. H ₂ O	inches of water
CARB	California Air Resources Board	eng.	engine	in. Hg	inches of mercury
CB	circuit breaker	EPA	Environmental Protection Agency	in. lb.	inch pounds
cc	cubic centimeter	EPS	emergency power system	Inc.	incorporated
CCA	cold cranking amps	ER	emergency relay	ind.	industrial
ccw.	counterclockwise	ES	engineering special, engineered special	int.	internal
CEC	Canadian Electrical Code	ESD	electrostatic discharge	int./ext.	internal/external
cert.	certificate, certification, certified	est.	estimated	I/O	input/output
cfh	cubic feet per hour	E-Stop	emergency stop	IP	iron pipe
		etc.	et cetera (and so forth)	ISO	International Organization for Standardization
				J	joule
				JIS	Japanese Industry Standard

k	kilo (1000)	MTBF	mean time between failure	RHM	round head machine (screw)
K	kelvin	MTBO	mean time between overhauls	rly.	relay
kA	kiloampere	mtg.	mounting	rms	root mean square
KB	kilobyte (2 ¹⁰ bytes)	MW	megawatt	rnd.	round
kg	kilogram	mW	milliwatt	ROM	read only memory
kg/cm ²	kilograms per square centimeter	μF	microfarad	rot.	rotate, rotating
kgm	kilogram-meter	N, norm.	normal (power source)	rpm	revolutions per minute
kg/m ³	kilograms per cubic meter	NA	not available, not applicable	RS	right side
kHz	kilohertz	nat. gas	natural gas	RTV	room temperature vulcanization
kJ	kilojoule	NBS	National Bureau of Standards	SAE	Society of Automotive Engineers
km	kilometer	NC	normally closed	scfm	standard cubic feet per minute
kOhm, kΩ	kilo-ohm	NEC	National Electrical Code	SCR	silicon controlled rectifier
kPa	kilopascal	NEMA	National Electrical Manufacturers Association	s, sec.	second
kph	kilometers per hour	NFPA	National Fire Protection Association	SI	<i>Système international d'unités</i> , International System of Units
kV	kilovolt	Nm	newton meter	SI/EO	side in/end out
kVA	kilovolt ampere	NO	normally open	sil.	silencer
kVAR	kilovolt ampere reactive	no., nos.	number, numbers	SN	serial number
kW	kilowatt	NPS	National Pipe, Straight	SPDT	single-pole, double-throw
kWh	kilowatt-hour	NPSC	National Pipe, Straight-coupling	SPST	single-pole, single-throw
kWm	kilowatt mechanical	NPT	National Standard taper pipe thread per general use	spec, specs	specification(s)
L	liter	NPTF	National Pipe, Taper-Fine	sq.	square
LAN	local area network	NR	not required, normal relay	sq. cm	square centimeter
L x W x H	length by width by height	ns	nanosecond	sq. in.	square inch
lb.	pound, pounds	OC	overcrank	SS	stainless steel
lbm/ft ³	pounds mass per cubic feet	OD	outside diameter	std.	standard
LCB	line circuit breaker	OEM	original equipment manufacturer	stl.	steel
LCD	liquid crystal display	OF	overfrequency	tach.	tachometer
ld. shd.	load shed	opt.	option, optional	TD	time delay
LED	light emitting diode	OS	oversize, overspeed	TDC	top dead center
Lph	liters per hour	OSHA	Occupational Safety and Health Administration	TDEC	time delay engine cooldown
Lpm	liters per minute	OV	overvoltage	TDEN	time delay emergency to normal
LOP	low oil pressure	oz.	ounce	TDES	time delay engine start
LP	liquefied petroleum	p., pp.	page, pages	TDNE	time delay normal to emergency
LPG	liquefied petroleum gas	PC	personal computer	TDOE	time delay off to emergency
LS	left side	PCB	printed circuit board	TDON	time delay off to normal
L _{wa}	sound power level, A weighted	pF	picofarad	temp.	temperature
LWL	low water level	PF	power factor	term.	terminal
LWT	low water temperature	ph., ∅	phase	TIF	telephone influence factor
m	meter, milli (1/1000)	PHC	Phillips head crimplite (screw)	TIR	total indicator reading
M	mega (10 ⁶ when used with SI units), male	PHH	Phillips hex head (screw)	tol.	tolerance
m ³	cubic meter	PHM	pan head machine (screw)	turbo.	turbocharger
m ³ /min.	cubic meters per minute	PLC	programmable logic control	typ.	typical (same in multiple locations)
mA	milliampere	PMG	permanent-magnet generator	UF	underfrequency
man.	manual	pot	potentiometer, potential	UHF	ultrahigh frequency
max.	maximum	ppm	parts per million	UL	Underwriter's Laboratories, Inc.
MB	megabyte (2 ²⁰ bytes)	PROM	programmable read-only memory	UNC	unified coarse thread (was NC)
MCM	one thousand circular mils	psi	pounds per square inch	UNF	unified fine thread (was NF)
MCCB	molded-case circuit breaker	pt.	pint	univ.	universal
meggar	megohmmeter	PTC	positive temperature coefficient	US	undersize, underspeed
MHz	megahertz	PTO	power takeoff	UV	ultraviolet, undervoltage
mi.	mile	PVC	polyvinyl chloride	V	volt
mil	one one-thousandth of an inch	qt.	quart, quarts	VAC	volts alternating current
min.	minimum, minute	qty.	quantity	VAR	voltampere reactive
misc.	miscellaneous	R	replacement (emergency) power source	VDC	volts direct current
MJ	megajoule	rad.	radiator, radius	VFD	vacuum fluorescent display
mJ	millijoule	RAM	random access memory	VGA	video graphics adapter
mm	millimeter	RDO	relay driver output	VHF	very high frequency
mOhm, mΩ	milliohm	ref.	reference	W	watt
MOhm, MΩ	megohm	rem.	remote	WCR	withstand and closing rating
MOV	metal oxide varistor	Res/Coml	Residential/Commercial	w/	with
MPa	megapascal	RFI	radio frequency interference	w/o	without
mpg	miles per gallon	RH	round head	wt.	weight
mph	miles per hour			xfmr	transformer
MS	military standard				
m/sec.	meters per second				

Appendix B Common Hardware Application Guidelines

Use the information below and on the following pages to identify proper fastening techniques when no specific reference for reassembly is made.

Bolt/Screw Length: When bolt/screw length is not given, use Figure 1 as a guide. As a general rule, a minimum length of one thread beyond the nut and a maximum length of 1/2 the bolt/screw diameter beyond the nut is the preferred method.

Washers and Nuts: Use split lock washers as a bolt locking device where specified. Use SAE flat washers with whiz nuts, spirallock nuts, or standard nuts and preloading (torque) of the bolt in all other applications.

See Appendix C, General Torque Specifications, and other torque specifications in the service literature.




Figure 1 Acceptable Bolt Lengths

Steps for common hardware application:

1. Determine entry hole type: round or slotted.
2. Determine exit hole type: fixed female thread (weld nut), round, or slotted.

For round and slotted exit holes, determine if hardware is greater than 1/2 inch in diameter, or 1/2 inch in diameter or less. Hardware that is *greater than 1/2 inch* in diameter takes a standard nut and SAE washer. Hardware *1/2 inch or less* in diameter can take a properly torqued whiz nut or spirallock nut. See Figure 2.

3. Follow these SAE washer rules after determining exit hole type:
 - a. Always use a washer between hardware and a slot.
 - b. Always use a washer under a nut (see 2 above for exception).
 - c. Use a washer under a bolt when the female thread is fixed (weld nut).
4. Refer to Figure 2, which depicts the preceding hardware configuration possibilities.




Figure 2 Acceptable Hardware Combinations

Appendix C General Torque Specifications















Use the following torque specifications when service literature instructions give no specific torque values. The charts list values for new plated, zinc phosphate, or












oiled threads. Increase values by 15% for nonplated threads. All torque values are +0%/-10%.






American Standard Fasteners Torque Specifications					
Size	Torque Measurement	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 2 or 5
		Grade 2	Grade 5	Grade 8	
8-32	Nm (in. lb.)	1.8 (16)	2.3 (20)	—	1.8 (16)
10-24	Nm (in. lb.)	2.9 (26)	3.6 (32)	—	2.9 (26)
10-32	Nm (in. lb.)	2.9 (26)	3.6 (32)	—	2.9 (26)
1/4-20	Nm (in. lb.)	6.8 (60)	10.8 (96)	14.9 (132)	6.8 (60)
1/4-28	Nm (in. lb.)	8.1 (72)	12.2 (108)	16.3 (144)	8.1 (72)
5/16-18	Nm (in. lb.)	13.6 (120)	21.7 (192)	29.8 (264)	13.6 (120)
5/16-24	Nm (in. lb.)	14.9 (132)	23.1 (204)	32.5 (288)	14.9 (132)
3/8-16	Nm (ft. lb.)	24.0 (18)	38.0 (28)	53.0 (39)	24.0 (18)
3/8-24	Nm (ft. lb.)	27.0 (20)	42.0 (31)	60.0 (44)	27.0 (20)
7/16-14	Nm (ft. lb.)	39.0 (29)	60.0 (44)	85.0 (63)	—
7/16-20	Nm (ft. lb.)	43.0 (32)	68.0 (50)	95.0 (70)	—
1/2-13	Nm (ft. lb.)	60.0 (44)	92.0 (68)	130.0 (96)	—
1/2-20	Nm (ft. lb.)	66.0 (49)	103.0 (76)	146.0 (108)	—
9/16-12	Nm (ft. lb.)	81.0 (60)	133.0 (98)	187.0 (138)	—
9/16-18	Nm (ft. lb.)	91.0 (67)	148.0 (109)	209.0 (154)	—
5/8-11	Nm (ft. lb.)	113.0 (83)	183.0 (135)	259.0 (191)	—
5/8-18	Nm (ft. lb.)	128.0 (94)	208.0 (153)	293.0 (216)	—
3/4-10	Nm (ft. lb.)	199.0 (147)	325.0 (240)	458.0 (338)	—
3/4-16	Nm (ft. lb.)	222.0 (164)	363.0 (268)	513.0 (378)	—
1-8	Nm (ft. lb.)	259.0 (191)	721.0 (532)	1109.0 (818)	—
1-12	Nm (ft. lb.)	283.0 (209)	789.0 (582)	1214.0 (895)	—

Metric Fasteners Torque Specifications, Measured in Nm (ft. lb.)					
Size (mm)	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 5.8 or 8.8	
	Grade 5.8	Grade 8.8	Grade 10.9		
M6 x 1.00	5.6 (4)	9.9 (7)	14.0 (10)	5.6 (4)	
M8 x 1.25	13.6 (10)	25.0 (18)	35.0 (26)	13.6 (10)	
M8 x 1.00	21.0 (16)	25.0 (18)	35.0 (26)	21.0 (16)	
M10 x 1.50	27.0 (20)	49.0 (35)	68.0 (50)	27.0 (20)	
M10 x 1.25	39.0 (29)	49.0 (35)	68.0 (50)	39.0 (29)	
M12 x 1.75	47.0 (35)	83.0 (61)	117.0 (86)	—	
M12 x 1.50	65.0 (48)	88.0 (65)	125.0 (92)	—	
M14 x 2.00	74.0 (55)	132.0 (97)	185.0 (136)	—	
M14 x 1.50	100.0 (74)	140.0 (103)	192.0 (142)	—	
M16 x 2.00	115.0 (85)	200.0 (148)	285.0 (210)	—	
M16 x 1.50	141.0 (104)	210.0 (155)	295.0 (218)	—	
M18 x 2.50	155.0 (114)	275.0 (203)	390.0 (288)	—	
M18 x 1.50	196.0 (145)	305.0 (225)	425.0 (315)	—	

Appendix D Common Hardware Identification

Screw/Bolts/Studs	
Head Styles	
Hex Head or Machine Head	
Hex Head or Machine Head with Washer	
Flat Head (FHM)	
Round Head (RHM)	
Pan Head	
Hex Socket Head Cap or Allen™ Head Cap	
Hex Socket Head or Allen™ Head Shoulder Bolt	
Sheet Metal Screw	
Stud	
Drive Styles	
Hex	
Hex and Slotted	
Phillips®	
Slotted	
Hex Socket	

Nuts	
Nut Styles	
Hex Head	
Lock or Elastic	
Square	
Cap or Acorn	
Wing	
Washers	
Washer Styles	
Plain	
Split Lock or Spring	
Spring or Wave	
External Tooth Lock	
Internal Tooth Lock	
Internal-External Tooth Lock	


Hardness Grades	
American Standard	
Grade 2	
Grade 5	
Grade 8	
Grade 8/9 (Hex Socket Head)	
Metric	
Number stamped on hardware; 5.8 shown	

Allen™ head screw is a trademark of Holo-Krome Co.


Phillips® screw is a registered trademark of Phillips Screw Company.

Sample Dimensions


American Standard (Screws, Bolts, Studs, and Nuts)



Metric (Screws, Bolts, Studs, and Nuts)



Plain Washers



Lock Washers



Appendix E Common Hardware List

The Common Hardware List lists part numbers and dimensions for common hardware items.

American Standard

Part No. Dimensions Hex Head Bolts (Grade 5)

X-465-17	1/4-20 x .38
X-465-6	1/4-20 x .50
X-465-2	1/4-20 x .62
X-465-16	1/4-20 x .75
X-465-18	1/4-20 x .88
X-465-7	1/4-20 x 1.00
X-465-8	1/4-20 x 1.25
X-465-9	1/4-20 x 1.50
X-465-10	1/4-20 x 1.75
X-465-11	1/4-20 x 2.00
X-465-12	1/4-20 x 2.25
X-465-14	1/4-20 x 2.75
X-465-21	1/4-20 x 5.00
X-465-25	1/4-28 x .38
X-465-20	1/4-28 x 1.00
X-125-33	5/16-18 x .50
X-125-23	5/16-18 x .62
X-125-3	5/16-18 x .75
X-125-31	5/16-18 x .88
X-125-5	5/16-18 x 1.00
X-125-24	5/16-18 x 1.25
X-125-34	5/16-18 x 1.50
X-125-25	5/16-18 x 1.75
X-125-26	5/16-18 x 2.00
230578	5/16-18 x 2.25
X-125-29	5/16-18 x 2.50
X-125-27	5/16-18 x 2.75
X-125-28	5/16-18 x 3.00
X-125-22	5/16-18 x 4.50
X-125-32	5/16-18 x 5.00
X-125-35	5/16-18 x 5.50
X-125-36	5/16-18 x 6.00
X-125-40	5/16-18 x 6.50
X-125-43	5/16-24 x 1.75
X-125-44	5/16-24 x 2.50
X-125-30	5/16-24 x .75
X-125-39	5/16-24 x 2.00
X-125-38	5/16-24 x 2.75
X-6238-2	3/8-16 x .62
X-6238-10	3/8-16 x .75
X-6238-3	3/8-16 x .88
X-6238-11	3/8-16 x 1.00
X-6238-4	3/8-16 x 1.25
X-6238-5	3/8-16 x 1.50
X-6238-1	3/8-16 x 1.75
X-6238-6	3/8-16 x 2.00
X-6238-17	3/8-16 x 2.25
X-6238-7	3/8-16 x 2.50
X-6238-8	3/8-16 x 2.75
X-6238-9	3/8-16 x 3.00
X-6238-19	3/8-16 x 3.25
X-6238-12	3/8-16 x 3.50
X-6238-20	3/8-16 x 3.75
X-6238-13	3/8-16 x 4.50
X-6238-18	3/8-16 x 5.50
X-6238-25	3/8-16 x 6.50

Part No. Dimensions Hex Head Bolts, cont.

X-6238-14	3/8-24 x .75
X-6238-16	3/8-24 x 1.25
X-6238-21	3/8-24 x 4.00
X-6238-22	3/8-24 x 4.50
X-6024-5	7/16-14 x .75
X-6024-2	7/16-14 x 1.00
X-6024-8	7/16-14 x 1.25
X-6024-3	7/16-14 x 1.50
X-6024-4	7/16-14 x 2.00
X-6024-11	7/16-14 x 2.75
X-6024-12	7/16-14 x 6.50
X-129-15	1/2-13 x .75
X-129-17	1/2-13 x 1.00
X-129-18	1/2-13 x 1.25
X-129-19	1/2-13 x 1.50
X-129-20	1/2-13 x 1.75
X-129-21	1/2-13 x 2.00
X-129-22	1/2-13 x 2.25
X-129-23	1/2-13 x 2.50
X-129-24	1/2-13 x 2.75
X-129-25	1/2-13 x 3.00
X-129-27	1/2-13 x 3.50
X-129-29	1/2-13 x 4.00
X-129-30	1/2-13 x 4.50
X-463-9	1/2-13 x 5.50
X-129-44	1/2-13 x 6.00
X-129-51	1/2-20 x .75
X-129-45	1/2-20 x 1.25
X-129-52	1/2-20 x 1.50
X-6021-3	5/8-11 x 1.00
X-6021-4	5/8-11 x 1.25
X-6021-2	5/8-11 x 1.50
X-6021-1	5/8-11 x 1.75
273049	5/8-11 x 2.00
X-6021-5	5/8-11 x 2.25
X-6021-6	5/8-11 x 2.50
X-6021-7	5/8-11 x 2.75
X-6021-12	5/8-11 x 3.75
X-6021-11	5/8-11 x 4.50
X-6021-10	5/8-11 x 6.00
X-6021-9	5/8-18 x 2.50
X-6239-1	3/4-10 x 1.00
X-6239-8	3/4-10 x 1.25
X-6239-2	3/4-10 x 1.50
X-6239-3	3/4-10 x 2.00
X-6239-4	3/4-10 x 2.50
X-6239-5	3/4-10 x 3.00
X-6239-6	3/4-10 x 3.50
X-792-1	1-8 x 2.25
X-792-5	1-8 x 3.00
X-792-8	1-8 x 5.00

Part No. Dimensions Type

Hex Nuts

X-6009-1	1-8	Standard
X-6210-3	6-32	Whiz
X-6210-4	8-32	Whiz
X-6210-5	10-24	Whiz
X-6210-1	10-32	Whiz
X-6210-2	1/4-20	Spiralock
X-6210-6	1/4-28	Spiralock
X-6210-7	5/16-18	Spiralock
X-6210-8	5/16-24	Spiralock
X-6210-9	3/8-16	Spiralock
X-6210-10	3/8-24	Spiralock
X-6210-11	7/16-14	Spiralock
X-6210-12	1/2-13	Spiralock
X-6210-15	7/16-20	Spiralock
X-6210-14	1/2-20	Spiralock
X-85-3	5/8-11	Standard
X-88-12	3/4-10	Standard
X-89-2	1/2-20	Standard

Washers

Part No.	ID	OD	Thick.	Bolt/ Screw
X-25-46	.125	.250	.022	#4
X-25-9	.156	.375	.049	#6
X-25-48	.188	.438	.049	#8
X-25-36	.219	.500	.049	#10
X-25-40	.281	.625	.065	1/4
X-25-85	.344	.687	.065	5/16
X-25-37	.406	.812	.065	3/8
X-25-34	.469	.922	.065	7/16
X-25-26	.531	1.062	.095	1/2
X-25-15	.656	1.312	.095	5/8
X-25-29	.812	1.469	.134	3/4
X-25-127	1.062	2.000	.134	1

Metric

Hex head bolts are hardness grade 8.8 unless noted.

Part No.	Dimensions	Part No.	Dimensions	Part No.	Dimensions
Hex Head Bolts (Partial Thread)		Hex Head Bolts (Partial Thread), continued		Hex Head Bolts (Full Thread), continued	
M931-05055-60	M5-0.80 x 55	M960-16090-60	M16-1.50 x 90	M933-12016-60	M12-1.75 x 16
M931-06040-60	M6-1.00 x 40	M931-16090-60	M16-2.00 x 90	M933-12020-60	M12-1.75 x 20
M931-06055-60	M6-1.00 x 55	M931-16100-60	M16-2.00 x 100	M961-12020-60F	M12-1.50 x 20
M931-06060-60	M6-1.00 x 60	M931-16100-82	M16-2.00 x 100*	M933-12025-60	M12-1.75 x 25
M931-06060-SS	M6-1.00 x 60	M931-16120-60	M16-2.00 x 120	M933-12025-82	M12-1.75 x 25*
M931-06070-60	M6-1.00 x 70	M931-16150-60	M16-2.00 x 150	M961-12030-60	M12-1.25 x 30
M931-06070-SS	M6-1.00 x 70			M933-12030-82	M12-1.75 x 30*
M931-06075-60	M6-1.00 x 75	M931-20065-60	M20-2.50 x 65	M961-12030-82F	M12-1.50 x 30*
M931-06090-60	M6-1.00 x 90	M931-20090-60	M20-2.50 x 90	M933-12030-60	M12-1.75 x 30
M931-06145-60	M6-1.00 x 145	M931-20100-60	M20-2.50 x 100	M933-12035-60	M12-1.75 x 35
M931-06150-60	M6-1.00 x 150	M931-20120-60	M20-2.50 x 120	M961-12040-82	M12-1.25 x 40*
		M931-20140-60	M20-2.50 x 140	M933-12040-60	M12-1.75 x 40
M931-08035-60	M8-1.25 x 35	M931-20160-60	M20-2.50 x 160	M933-12040-82	M12-1.75 x 40*
M931-08040-60	M8-1.25 x 40				
M931-08045-60	M8-1.25 x 45	M931-22090-60	M22-2.50 x 90	M961-14025-60	M14-1.50 x 25
M931-08050-60	M8-1.25 x 50	M931-22120-60	M22-2.50 x 120	M933-14025-60	M14-2.00 x 25
M931-08055-60	M8-1.25 x 55	M931-22160-60	M22-2.50 x 160	M961-14050-82	M14-1.50 x 50*
M931-08055-82	M8-1.25 x 55*				
M931-08060-60	M8-1.25 x 60	M931-24090-60	M24-3.00 x 90	M961-16025-60	M16-1.50 x 25
M931-08070-60	M8-1.25 x 70	M931-24120-60	M24-3.00 x 120	M933-16025-60	M16-2.00 x 25
M931-08070-82	M8-1.25 x 70*	M931-24160-60	M24-3.00 x 160	M961-16030-82	M16-1.50 x 30*
M931-08075-60	M8-1.25 x 75	M931-24200-60	M24-3.00 x 200	M933-16030-82	M16-2.00 x 30*
M931-08080-60	M8-1.25 x 80			M933-16035-60	M16-2.00 x 35
M931-08090-60	M8-1.25 x 90	Hex Head Bolts (Full Thread)		M961-16040-60	M16-1.50 x 40
M931-08095-60	M8-1.25 x 95	M933-04006-60	M4-0.70 x 6	M933-16040-60	M16-2.00 x 40
M931-08100-60	M8-1.25 x 100			M961-16045-82	M16-1.50 x 45*
M931-08110-60	M8-1.25 x 110	M933-05030-60	M5-0.80 x 30	M933-16045-82	M16-2.00 x 45*
M931-08120-60	M8-1.25 x 120	M933-05035-60	M5-0.80 x 35	M933-16050-60	M16-2.00 x 50
M931-08130-60	M8-1.25 x 130	M933-05050-60	M5-0.80 x 50	M933-16050-82	M16-2.00 x 50*
M931-08140-60	M8-1.25 x 140			M933-16060-60	M16-2.00 x 60
M931-08150-60	M8-1.25 x 150	M933-06010-60	M6-1.00 x 10	M933-16070-60	M16-2.00 x 70
M931-08200-60	M8-1.25 x 200	M933-06012-60	M6-1.00 x 12		
		M933-06014-60	M6-1.00 x 14	M933-18035-60	M18-2.50 x 35
M931-10040-82	M10-1.25 x 40*	M933-06016-60	M6-1.00 x 16	M933-18050-60	M18-2.50 x 50
M931-10040-60	M10-1.50 x 40	M933-06020-60	M6-1.00 x 20	M933-18060-60	M18-2.50 x 60
M931-10045-60	M10-1.50 x 45	M933-06025-60	M6-1.00 x 25		
M931-10050-60	M10-1.50 x 50	M933-06030-60	M6-1.00 x 30	M933-20050-60	M20-2.50 x 50
M931-10050-82	M10-1.25 x 50*	M933-06040-60	M6-1.00 x 40	M933-20055-60	M20-2.50 x 55
M931-10055-60	M10-1.50 x 55	M933-06050-60	M6-1.00 x 50		
M931-10060-60	M10-1.50 x 60			M933-24060-60	M24-3.00 x 60
M931-10065-60	M10-1.50 x 65	M933-07025-60	M7-1.00 x 25	M933-24065-60	M24-3.00 x 65
M931-10070-60	M10-1.50 x 70			M933-24070-60	M24-3.00 x 70
M931-10080-60	M10-1.50 x 80	M933-08010-60	M8-1.25 x 10		
M931-10080-82	M10-1.25 x 80*	M933-08012-60	M8-1.25 x 12	Pan Head Machine Screws	
M931-10090-60	M10-1.50 x 90	M933-08016-60	M8-1.25 x 16	M7985A-03010-20	M3-0.50 x 10
M931-10090-82	M10-1.50 x 90*	M933-08020-60	M8-1.25 x 20	M7985A-03012-20	M3-0.50 x 12
M931-10100-60	M10-1.50 x 100	M933-08025-60	M8-1.25 x 25	M7985A-04010-20	M4-0.70 x 10
M931-10110-60	M10-1.50 x 110	M933-08030-60	M8-1.25 x 30	M7985A-04016-20	M4-0.70 x 16
M931-10120-60	M10-1.50 x 120	M933-08030-82	M8-1.25 x 30*	M7985A-04020-20	M4-0.70 x 20
M931-10130-60	M10-1.50 x 130			M7985A-04050-20	M4-0.70 x 50
M931-10140-60	M10-1.50 x 140	M933-10012-60	M10-1.50 x 12	M7985A-04100-20	M4-0.70 x 100
M931-10180-60	M10-1.50 x 180	M961-10020-60	M10-1.25 x 20		
M931-10235-60	M10-1.50 x 235	M933-10020-60	M10-1.50 x 20	M7985A-05010-20	M5-0.80 x 10
M931-10260-60	M10-1.50 x 260	M933-10025-60	M10-1.50 x 25	M7985A-05012-20	M5-0.80 x 12
M960-10330-60	M10-1.25 x 330	M961-10025-60	M10-1.25 x 25	M7985A-05016-20	M5-0.80 x 16
		M933-10025-82	M10-1.50 x 25*	M7985A-05020-20	M5-0.80 x 20
M931-12045-60	M12-1.75 x 45	M961-10030-60	M10-1.25 x 30	M7985A-05025-20	M5-0.80 x 25
M960-12050-60	M12-1.25 x 50	M933-10030-60	M10-1.50 x 30	M7985A-05030-20	M5-0.80 x 30
M960-12050-82	M12-1.25 x 50*	M933-10030-82	M10-1.50 x 30*	M7985A-05080-20	M5-0.80 x 80
M931-12050-60	M12-1.75 x 50	M961-10035-60	M10-1.25 x 35	M7985A-05100-20	M5-0.80 x 100
M931-12050-82	M12-1.75 x 50*	M933-10035-60	M10-1.50 x 35		
M931-12055-60	M12-1.75 x 55	M933-10035-82	M10-1.50 x 35*	M7985A-06100-20	M6-1.00 x 100
M931-12060-60	M12-1.75 x 60	M961-10040-60	M10-1.25 x 40		
M931-12060-82	M12-1.75 x 60*			Flat Head Machine Screws	
M931-12065-60	M12-1.75 x 65			M965A-04012-SS	M4-0.70 x 12
M931-12075-60	M12-1.75 x 75				
M931-12080-60	M12-1.75 x 80			M965A-05012-SS	M5-0.80 x 12
M931-12090-60	M12-1.75 x 90			M965A-05016-20	M5-0.80 x 16
M931-12100-60	M12-1.75 x 100			M965A-06012-20	M6-1.00 x 12
M931-12110-60	M12-1.75 x 110				

* This metric hex bolt's hardness is grade 10.9.

Metric, continued

Part No.	Dimensions	Type
Hex Nuts		
M934-03-50	M3-0.50	Standard
M934-04-50	M4-0.70	Standard
M934-04-B	M4-0.70	Brass
M934-05-50	M5-0.80	Standard
M934-06-60	M6-1.00	Standard
M934-06-64	M6-1.00	Std. (green)
M6923-06-80	M6-1.00	Spirallock
M982-06-80	M6-1.00	Elastic Stop
M934-08-60	M8-1.25	Standard
M6923-08-80	M8-1.25	Spirallock
M982-08-80	M8-1.25	Elastic Stop
M934-10-60	M10-1.50	Standard
M934-10-60F	M10-1.25	Standard
M6923-10-80	M10-1.50	Spirallock
M6923-10-62	M10-1.50	Spirallock†
M982-10-80	M10-1.50	Elastic Stop
M934-12-60	M12-1.75	Standard
M934-12-60F	M12-1.25	Standard
M6923-12-80	M12-1.75	Spirallock
M982-12-80	M12-1.75	Elastic Stop
M982-14-60	M14-2.00	Elastic Stop
M6923-16-80	M16-2.00	Spirallock
M982-16-80	M16-2.00	Elastic Stop
M934-18-80	M18-2.5	Standard
M982-18-60	M18-2.50	Elastic Stop
M934-20-80	M20-2.50	Standard
M982-20-80	M20-2.50	Elastic Stop
M934-22-60	M22-2.50	Standard
M934-24-80	M24-3.00	Standard
M982-24-60	M24-3.00	Elastic Stop
M934-30-80	M30-3.50	Standard

Washers

Part No.	ID	OD	Thick.	Bolt/ Screw
M125A-03-80	3.2	7.0	0.5	M3
M125A-04-80	4.3	9.0	0.8	M4
M125A-05-80	5.3	10.0	1.0	M5
M125A-06-80	6.4	12.0	1.6	M6
M125A-08-80	8.4	16.0	1.6	M8
M125A-10-80	10.5	20.0	2.0	M10
M125A-12-80	13.0	24.0	2.5	M12
M125A-14-80	15.0	28.0	2.5	M14
M125A-16-80	17.0	30.0	3.0	M16
M125A-18-80	19.0	34.0	3.0	M18
M125A-20-80	21.0	37.0	3.0	M20
M125A-24-80	25.0	44.0	4.0	M24

† This metric hex nut's hardness is grade 8.

TP-6053 7/04a

© 2000 and 2004 by Kohler Co. All rights reserved.

KOHLER[®] POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044
Phone 920-565-3381, Fax 920-459-1646
For the nearest sales/service outlet in the
US and Canada, phone 1-800-544-2444
KohlerPowerSystems.com

Kohler Power Systems
Asia Pacific Headquarters
7 Jurong Pier Road
Singapore 619159
Phone (65)6264-6422, Fax (65)6264-6455